

AltairZ80 Simulator Usage

16-Aug-2020

COPYRIGHT NOTICE

The following copyright notice applies to the SIMH source, binary, and documentation:

Original code for the AltairZ80 part published in 2002-2014, written by Peter Schorn
Copyright (c) 2002-2020, Peter Schorn

Permission is hereby granted, free of charge, to any person obtaining a copy of this software and associated documentation files (the "Software"), to deal in the Software without restriction, including without limitation the rights to use, copy, modify, merge, publish, distribute, sublicense, and/or sell copies of the Software, and to permit persons to whom the Software is furnished to do so, subject to the following conditions:

The above copyright notice and this permission notice shall be included in all copies or substantial portions of the Software.

THE SOFTWARE IS PROVIDED "AS IS", WITHOUT WARRANTY OF ANY KIND, EXPRESS OR IMPLIED, INCLUDING BUT NOT LIMITED TO THE WARRANTIES OF MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE AND NONINFRINGEMENT. IN NO EVENT SHALL PETER SCHORN BE LIABLE FOR ANY CLAIM, DAMAGES OR OTHER LIABILITY, WHETHER IN AN ACTION OF CONTRACT, TORT OR OTHERWISE, ARISING FROM, OUT OF OR IN CONNECTION WITH THE SOFTWARE OR THE USE OR OTHER DEALINGS IN THE SOFTWARE.

Except as contained in this notice, the name of Peter Schorn shall not be used in advertising or otherwise to promote the sale, use or other dealings in this Software without prior written authorization from Peter Schorn.

Based on work by Charles E. Owen (c) 1997. Additional device support by Howard M. Harte, Ernie Price, Mike Douglas and Patrick Linstruth.

| | | |
|-------|---|----|
| 1 | Simulator Files | 4 |
| 2 | Revision History | 6 |
| 3 | Background | 8 |
| 4 | Hardware..... | 8 |
| 4.1 | CPU | 9 |
| 4.1.1 | Registers for the 8080 and Z80 | 10 |
| 4.1.2 | Registers for the 8086..... | 12 |
| 4.1.3 | Registers for the MC68000..... | 13 |
| 4.2 | The Serial I/O Card (2SIO)..... | 14 |
| 4.3 | MIT 88-2SIO Serial Adapter (M2SIO)..... | 16 |
| 4.3.1 | Using the M2SIO device with serial ports..... | 17 |
| 4.3.2 | Using the M2SIO device with sockets..... | 17 |
| 4.3.3 | M2SIO limitations..... | 18 |
| 4.4 | The SIMH pseudo device..... | 18 |
| 4.5 | The 88-DISK controller..... | 18 |
| 4.6 | The 88-HDSK controller | 19 |
| 4.7 | The simulated hard disk..... | 19 |
| 4.8 | The simulated network..... | 21 |
| 5 | Sample Software..... | 21 |
| 5.1 | CP/M Version 2.2..... | 22 |
| 5.2 | CP/M Version 3 with banked memory..... | 25 |
| 5.3 | MP/M II with banked memory..... | 27 |
| 5.4 | CP/NET | 30 |
| 5.5 | CPNOS | 31 |
| 5.6 | CP/M application software | 31 |
| 5.7 | MIT 88 Disk Extended BASIC Version 4.1..... | 34 |
| 5.8 | Altair DOS Version 1.0 | 34 |
| 5.9 | Altair Basic 3.2 (4k)..... | 35 |
| 5.10 | Altair Basic 4.0 (4k)..... | 35 |
| 5.11 | Altair 8k Basic | 36 |
| 5.12 | Altair Basic 4.0 | 36 |
| 5.13 | Altair Disk Extended Basic Version 300-5-C | 37 |
| 5.14 | Altair Disk Extended Basic Version 5.0 | 37 |
| 5.15 | Altair Hard Disk Basic 300-5-C..... | 38 |
| 5.16 | Altair programming languages VTL-2 and MINOL | 39 |
| 5.17 | UCSD Pascal II.0 | 39 |
| 5.18 | CP/M-68K | 40 |
| 6 | Special simulator features..... | 40 |
| 6.1 | Memory access breakpoints (8080/Z80 only)..... | 40 |
| 6.2 | Instruction breakpoints (8080/Z80/8086)..... | 40 |
| 6.3 | Breakpoints and instruction history (8080/Z80 only) | 40 |
| 7 | Brief summary of all major changes to the original Altair simulator | 41 |
| 8 | Appendix: Python script for converting MBL files to plain binary files..... | 41 |
| 9 | Appendix: How to bring up UCSD Pascal II.0 on SIMH..... | 43 |
| 10 | Vector Graphic, Inc. Simulation..... | 51 |
| 10.1 | Overview | 51 |

| | | |
|--------|---|----|
| 10.2 | 48K Vector MZ | 52 |
| 10.3 | 56K Vector MZ | 53 |
| 10.4 | 56K Vector with HD-FD Controller | 53 |
| 10.5 | Notes on Simulated Hardware | 54 |
| 10.6 | Notes on the Vector Graphic Disk Image (VGI) File Format..... | 54 |
| 11 | IMSAI 8080 Simulation..... | 55 |
| 11.1 | Overview | 55 |
| 11.2 | IMSAI 8080 with FIF Disk Controller | 55 |
| 12 | North Star MDS-A and MDS-AD FDC Simulation | 56 |
| 12.1 | Overview | 56 |
| 12.2 | MDS-A Single Density Disk Controller | 56 |
| 12.3 | MDS-AD Double Density Disk Controller | 56 |
| 13 | Compupro 8-16 Simulation..... | 58 |
| 13.1 | Overview | 58 |
| 13.2 | DISK1A High Performance Floppy Disk Controller | 58 |
| 13.2.1 | DISK1A Controller Parameters..... | 58 |
| 13.2.2 | DISK1A Controller Limitations | 59 |
| 13.3 | DISK2 Compupro Hard Disk Controller..... | 59 |
| 13.3.1 | DISK2 Controller Parameters | 59 |
| 13.3.2 | DISK2 Controller Configuration Registers..... | 60 |
| 13.4 | SELCHAN Compupro Selector Channel Controller..... | 60 |
| 13.4.1 | DISK2 Controller Parameters..... | 60 |
| 13.5 | DISK3 Viasyn ST-506 Hard Disk Controller | 60 |
| 13.5.1 | DISK3 Controller Parameters | 60 |
| 13.5.2 | DISK3 Controller Configuration Registers..... | 61 |
| 13.5.3 | DISK3 Controller Limitations | 61 |
| 14 | Cromemco 4/16/64FDC and CCS-2422 FDC Simulation..... | 62 |
| 14.1 | Overview | 62 |
| 14.1.1 | CROMFDC Controller Parameters | 62 |
| 14.1.2 | CROMFDC Controller Configuration Registers | 62 |
| 14.1.3 | CROMFDC Controller Limitations..... | 63 |
| 16 | Tarbelle MDL-1011/2022 Floppy Disk Interface Simulation | 64 |
| 16.1 | Overview | 64 |
| 16.1.1 | TARBELL Controller Parameters..... | 64 |
| 16.1.2 | TARBELL Example Usage | 65 |
| 16.1.3 | TARBELL Controller Limitations..... | 65 |
| 17 | JADE Double D Floppy Disk Controller Simulation | 66 |
| 17.1 | Overview | 66 |
| 17.1.1 | JADE Double D Controller Parameters..... | 66 |
| 17.1.2 | JADEDD Example Usage..... | 66 |
| 17.1.3 | JADE Double D Controller Limitations..... | 67 |
| 18 | Advanced Digital Corporation Super-Six Simulation | 68 |
| 18.1 | Overview | 68 |
| 18.1.1 | ADCS6 SBC Parameters | 68 |
| 18.1.2 | ADCS6 SBC Configuration Registers | 68 |
| 18.1.3 | ADCS6 SBC Limitations..... | 69 |
| 19 | N8VEM Single Board Computer Simulation | 70 |
| 19.1 | Overview | 70 |
| 19.1.1 | N8VEM SBC Parameters..... | 70 |
| 19.1.2 | N8VEM SBC Configuration Registers..... | 70 |

| | | |
|--------|--|----|
| 19.1.3 | N8VEM SBC Limitations | 71 |
| 20 | PMMI MM-103 MODEM and Communications Adapter | 72 |
| 20.1 | Overview | 72 |
| 20.1.1 | PMMI Device Parameters | 72 |
| 20.1.2 | PMMI Example Usage | 72 |
| 20.1.3 | PMMI and SIMH Timing | 75 |
| 21 | Hayes Micromodem 100 | 76 |
| 21.1 | Overview | 76 |
| 21.1.1 | HAYES Device Parameters..... | 76 |
| 21.1.2 | HAYES Example Usage..... | 76 |
| 21.1.3 | HAYES and SIMH Timing | 78 |
| 22 | ImageDisk (IMD) Disk Image Support in SIMH | 80 |
| 22.1 | Overview | 80 |
| 22.2 | References..... | 80 |
| 23 | CP/M-68K Simulation | 80 |

This memorandum documents the Altair 8800 Simulator.

1 Simulator Files

```

scp.h
sim_console.h
sim_defs.h
sim_fio.h
sim_rev.h
sim_sock.h
sim_timer.h
sim_tmxr.h
sim_serial.h
sim_tape.c
sim_disk.c
sim_ether.c
scp.c
sim_console.c
sim_fio.c
sim_sock.c
sim_timer.c
sim_tmxr.c
sim_serial.c
sim_tape.c
sim_disk.c
sim_ether.c

```

| | |
|----------------------------|---|
| sim_imd.c | (ImageDisk Disk Image File access module by Howard M. Harte) |
| sim_imd.h | (ImageDisk Disk Image File access module by Howard M. Harte) |
| AltairZ80/altairz80_defs.h | |
| altairz80_cpu_nommu.c | |
| altairz80_cpu.c | |
| altairz80_dsk.c | |
| altairz80_hdisk.c | |
| altairz80_mhdisk.c | (MITS/Pertec 88-HDSK hard disk support by Mike Douglas) |
| altairz80_net.c | |
| altairz80_sio.c | |
| altairz80_sys.c | |
| flashwriter2.c | (Vector Graphic, Inc. FlashWriter II support by Howard M. Harte) |
| i8272.c | (Generic Intel 8272 Disk Controller by Howard M. Harte) |
| i8272.h | (Generic Intel 8272 Disk Controller by Howard M. Harte) |
| mfdc.c | (Micropolis FDC support by Howard M. Harte) |
| mfdc.h | (Micropolis FDC support by Howard M. Harte) |
| n8vem.c | (N8VEM Single-Board Computer I/O module by Howard M. Harte) |
| s100_2sio.c | (MITS 88-2SIO Serial Adapter by Patrick Linstruth) |
| s100_64fdc.c | (Cromemco 4FDC/16FDC/64FDC Floppy Controller by Howard M. Harte) |
| s100_adcs6.c | (Advanced Digital Corporation (ADC) Super-Six CPU Board by Howard M. Harte) |
| s100_disk1a.c | (CompuPro DISK1A Floppy Controller by Howard M. Harte) |
| s100_disk2.c | (CompuPro DISK2 Hard Disk Controller by Howard M. Harte) |
| s100_disk3.c | (CompuPro DISK3 Hard Disk Controller by Howard M. Harte) |
| s100_fif.c | (IMSAI FIF Disk Controller by Ernie Price) |
| s100_hayes.c | (Hayes 80-103A and Micromodem 100 by Patrick Linstruth) |
| s100_hdc1001.c | (Advanced Digital Corporation (ADC) HDC-1001 Hard Disk Controller by Howard M. Harte) |
| s100_if3.c | (CompuPro System Support 1 by Howard M. Harte) |
| s100_jadedd.c | (JADE Double D Disk Controller by Patrick Linstruth) |
| s100_mdriveh.c | (CompuPro M-DRIVE/H Controller by Howard M. Harte) |
| s100_mdsa.c | (Northstar MDS-A Single Density Disk Controller by Mike Douglas) |
| s100_mdsad.c | (Northstar MDS-AD disk controller by Howard M. Harte) |
| s100_pmml.c | (PMMI MM-103 MODEM by Patrick Linstruth) |
| s100_scp300f.c | (Seattle Computer Products SCP300F Support Board module by Howard M. Harte) |
| s100_selchan.c | (CompuPro Selector Channel module by Howard M. Harte) |
| s100_ss1.c | (CompuPro System Support 1 module by Howard M. Harte) |

| | |
|-----------------|--|
| s100_tarbell.c | (Altair Tarbell controller by Patrick Linstruth) |
| vfdhd.c | (Micropolis FDC support by Howard M. Harte) |
| vfdhd.h | (Micropolis FDC support by Howard M. Harte) |
| wd179x.h | (WD179X support by Howard M. Harte) |
| wd179x.c | (WD179X support by Howard M. Harte) |
| insns.h | (8086 Disassembler by Simon Tatham and Julian Hall) |
| nasm.h | (8086 Disassembler by Simon Tatham and Julian Hall) |
| disasm.c | (8086 Disassembler by Simon Tatham and Julian Hall) |
| insnsd.c | (8086 Disassembler by Simon Tatham and Julian Hall) |
| i86.h | (8086 CPU by Jim Hudgens) |
| i86_decode.c | (8086 CPU by Jim Hudgens) |
| i86_ops.c | (8086 CPU by Jim Hudgens) |
| i86_prim_ops.c | (8086 CPU by Jim Hudgens) |
| m68k.h | (Motorola M68000 CPU by Karl Stenerud) |
| m68kasm.y(.txt) | (Motorola M68000 assembler by Holger Veit, Bison source) |
| m68kasm.c | (Motorola M68000 assembler by Holger Veit, Bison output) |
| m68kconf.h | (Motorola M68000 CPU by Karl Stenerud) |
| m68ksim.c | (CPU driver or CP/M-68K simulation, based on work by David W. Schultz) |
| m68ksim.h | (CPU driver or CP/M-68K simulation, based on work by David W. Schultz) |
| m68kcpu.c | (Motorola MC68000 CPU by Karl Stenerud) |
| m68kcpu.h | (Motorola MC68000 CPU by Karl Stenerud) |
| m68kdasm.c | (Motorola MC68000 CPU by Karl Stenerud, disassembler) |
| m68kopac.c | (Motorola MC68000 CPU by Karl Stenerud) |
| m68kopdm.c | (Motorola MC68000 CPU by Karl Stenerud) |
| m68kopnz.c | (Motorola MC68000 CPU by Karl Stenerud) |
| m68kops.c | (Motorola MC68000 CPU by Karl Stenerud) |
| m68kops.h | (Motorola MC68000 CPU by Karl Stenerud) |

2 Revision History

- 14-Aug-2020, Patrick Linstruth (added support for Hayes S-100 modems)
- 02-Jul-2020, Patrick Linstruth (added support for PMMI MM-103 MODEM),
- 30-Jun-2020 Patrick Linstruth (added DSDD support to Tarbell disk controller)
- 29-Jun-2020 Patrick Linstruth (added support for MITS 88-2SIO)
- 10-Jun-2020, Mike Douglas (added documentation for North Star MDS-A (single density FDC))
- 05-Jun-2020, Peter Schorn (additional documentation for CPU SET commands and CPU pseudo registers)

- 04-Jun-2020, Patrick Linstruth (added support for the JADE Double D disk controller)
- 24-May-2020, Peter Schorn (added M68000 assembler based on Holger Veit's Bison code)
- 28-Apr-2020, Patrick Linstruth (added support for CPU instruction history)
- 09-Dec-2019, Peter Schorn (small updates)
- 05-Dec-2019, Patrick Linstruth (added support for the Altair Tarbell SSSD disk controller)
- 27-Dec-2015, Peter Schorn (updated SIO device documentation)
- 24-May-2014, Peter Schorn (added support for the Altair Mini-Disk contributed by Mike Douglas)
- 6-May-2014, Peter Schorn (added Motorola MC68000 CPU, updated HDSK and added a driver for CP/M-68K simulation)
- 21-Apr-2014, Peter Schorn (added debug flags for the MHDSK device and support for the NEXT command)
- 29-Mar-2014, Peter Schorn (added support for the MITS/Pertec 88-HDSK hard disk contributed by Mike Douglas)
- 15-Apr-2013, Peter Schorn (added correct cycle count timing for 8080 CPU, improved .IMD file processing, SIO 'C' switch was renamed to 'N')
- 24-Aug-2012, Peter Schorn (added capability to HDSK device for .IMD disk processing)
- 01-Aug-2011, Peter Schorn (added some explanation to Altair Basic)
- 29-Sep-2009, Peter Schorn (added debug flags to SIO, PTR and PTP)
- 18-Apr-2009, Peter Schorn (fixed some errata in the manual found by Kim Sparre and added additional disk layouts to HDSK)
- 17-Aug-2008, Peter Schorn (moved VERBOSE/QUIET for DSK and HDSK to debug flags)
- 03-Jul-2008, Howard M. Harte (added support for hardware modules from Cromemco, Advanced Digital Corporation, Seattle Computer Products and N8VEM)
- 29-Feb-2008, Howard M. Harte / Peter Schorn (added support for additional S100 and CompuPro hardware modules, added 8086 CPU)
- 29-Dec-2007, Howard M. Harte / Peter Schorn (added support for Vector Graphic Flashwriter II, Micropolis FDC, ImageDisk disk image File, IMSAI FIF disk controller, North Star MDS-AD disk controller)
- 21-Apr-2007, Peter Schorn (added documentation for UCSD Pascal II.0)
- 14-Apr-2007, Peter Schorn (added documentation for Howard M. Harte's hard disk extensions)
- 05-Jan-2007, Peter Schorn (added networking capability, included CP/NET and CPNOS)
- 26-Nov-2006, Peter Schorn (SIO can now be attached to a file, SIO rewritten for better efficiency)
- 15-Oct-2006, Peter Schorn (updated CP/M 2 operating system and application software description)
- 17-Sep-2006, Peter Schorn (added Altair Basic 5.0 to the sample software, corrected TTY/ANSI description)
- 21-Aug-2006, Peter Schorn (added MINOL and VTL-2 software, retyping courtesy of Emmanuel ROCHE, fixed a bug in memory breakpoints and added a create ("C") switch to the attach command)

- 24-Jan-2006, Peter Schorn (transcribed documentation to Word / PDF format)
- 05-Apr-2005, Peter Schorn (removed bogus t-state stepping support)
- 24-Jul-2004, Peter Schorn (updated CP/M 2 and SPL packages)
- 12-Apr-2004, Peter Schorn (added MAP/NOMAP capability to switch off key mapping)
- 26-Jan-2004, Peter Schorn (added support for t-state stepping)
- 25-Feb-2003, Peter Schorn (added support for real time simulation)
- 9-Oct-2002, Peter Schorn (added support for simulated hard disk)
- 28-Sep-2002, Peter Schorn (number of tracks per disk can be configured)
- 19-Sep-2002, Peter Schorn (added WARNROM feature)
- 31-Aug-2002, Peter Schorn (added extended ROM features suggested by Scott LaBombard)
- 4-May-2002, Peter Schorn (added description of MP/M II sample software)
- 28-Apr-2002, Peter Schorn (added periodic timer interrupts and three additional consoles)
- 15-Apr-2002, Peter Schorn (added memory breakpoint)
- 7-Apr-2002, Peter Schorn (added ALTAIRROM / NOALTAIRROM switch)

The first version of this document was written by Charles E. Owen

3 Background

The MITS (Micro Instrumentation and Telemetry Systems) Altair 8800 was announced on the January 1975 cover of Popular Electronics, which boasted you could buy and build this powerful computer kit for only \$397. The kit consisted at that time of only the parts to build a case, power supply, card cage (18 slots), CPU card, and memory card with 256 *bytes* of memory. Still, thousands were ordered within the first few months after the announcement, starting the personal computer revolution as we know it today.

Many laugh at the small size of that first kit, noting there were no peripherals and the 256 byte memory size. But the computer was an open system, and by 1977 MITS and many other small startups had added many expansion cards to make the Altair quite a respectable little computer. The "Altair Bus" that made this possible was soon called the S-100 Bus, later adopted as an industry standard, and eventually became the IEEE-696 Bus.

4 Hardware

We are simulating a fairly "loaded" Altair 8800 from about 1977, with the following configuration:

- CPU** Altair 8800 with Intel 8080 CPU board 62KB of RAM, 2K of EPROM with start boot ROM.
- SIO** MITS 88-2SIO Dual Serial Interface Board. Port 1 is assumed to be connected to a serial "glass TTY" that is your terminal running the simulator.
- PTR** Paper Tape Reader attached to port 2 of the 2SIO board.
- PTP** Paper Tape Punch attached to port 2 of the 2SIO board. This also doubles as a printer port.
- DSK** MITS 88-DISK Floppy Disk controller with up to eight drives.

4.1 CPU

We have three CPU options that were not present on the original machine but are useful in the simulator. We also allow you to select memory sizes, but be aware that some sample software requires the full 64K (i.e. CP/M) and the MITS Disk Basic and Altair DOS require about a minimum of 24K.

| | |
|--|--|
| SET CPU 8080 | Simulates the 8080 CPU (default) |
| SET CPU Z80 | Simulates the Z80 CPU. Note that some software (e.g. most original Altair software such as 4K Basic) requires an 8080 CPU and will not or not properly run on a Z80. This is mainly due to the use of the parity flag on the 8080 which has not always the same semantics on the Z80. |
| SET CPU 8086 | Simulates 8086 CPU. This also enables 1'024 KB of memory by default. |
| SET CPU M68K | Simulates Motorola M68000 CPU. This also enables 16 MB of memory by default. |
| SET CPU ITRAP | Causes the simulator to halt if an invalid opcode is detected (depending on the chosen CPU). |
| SET CPU NOITRAP | Does not stop on an invalid opcode. This is how the real 8080 works. Note that some software such as 4K Basic apparently tries to execute nonexistent 8080 instructions. Therefore it is advisable in this case to SET CPU NOITRAP. |
| SET CPU 4K SET CPU 8K SET CPU 12K SET CPU 16K ... (in 4K steps) SET CPU 64K | All these set various CPU memory configurations. |
| SET CPU MEMORY=<nnn>K | Sets the memory to <nnn> kilo bytes. |
| SET CPU BANKED | Enables the banked memory support. The simulated memory has eight banks with address range 0..'COMMON' (see registers below) and a common area from 'COMMON' to 0FFFF which is common to all banks. The currently active bank is determined by register 'BANK' (see below). You can only switch to banked memory if the memory is set to 64K. The banked memory is used by CP/M 3. |
| SET CPU NONBANKED | Disables banked memory support. |
| SET CPU CLEARMEMORY | Resets all internal memory to 0 and also resets the Memory Management Unit (MMU) such that all memory pages are RAM. Note that resetting the CPU does only clear the CPU registers but not the memory nor the MMU. |
| SET CPU ALTAIRROM | Enables the slightly modified but downwards compatible Altair boot ROM at addresses 0FF00 to 0FFFF. This is the default. |
| SET CPU NOALTAIRROM | Disables standard Altair ROM behavior. |

| | |
|----------------------|---|
| SET CPU MMU | Enables the Memory Management Unit (MMU) and clock frequency support. |
| SET CPU NOMMU | Disables the Memory Management Unit (MMU) and clock frequency support. The simulator will run with maximum speed which can be more than twice the speed as with MMU enabled. This feature is only available for the Z80 and 8080 CPU using 64 KB. |
| SET CPU AZ80 | Sets the RAM type to AltairZ80 RAM for 8080 / Z80 / 8086. |
| SET CPU HRAM | Sets the RAM type to NorthStar HRAM for 8080 / Z80 / 8086. |
| SET CPU VRAM | Sets the RAM type to Vector RAM for 8080 / Z80 / 8086. |
| SET CPU CRAM | Sets the RAM type to Cromemco RAM for 8080 / Z80 / 8086. |
| SET CPU SWITCHER | Sets the CPU switcher port for 8080 / Z80 / 8086 from the CPU pseudo-register SWITCHERPORT. |
| SET CPU NOSWITCHER | Resets the CPU switcher port for 8080 / Z80 / 8086. |
| SET CPU VERBOSE | Enables warning messages to be printed when the CPU attempts to write into ROM or into non-existing memory. Also prints a warning message if the CPU attempts to read from non-existing memory. Also shows the status of the MMU. |
| SET CPU QUIET | Suppresses all warning messages. |
| SET CPU STOPONHALT | Z80 or 8080 CPU stops when HALT instruction is encountered. |
| SET CPU LOOPONHALT | Z80 or 8080 CPU does not stop when a HALT instruction is encountered but waits for an interrupt to occur. |
| SET CPU HISTORY | Clears CPU instruction history buffer (8080 and Z80). |
| SET CPU HISTORY=0 | Disables CPU instruction history (8080 and Z80). |
| SET CPU HISTORY=<n> | Enables CPU instruction history buffer with a size of <n> (8080 and Z80). |
| SHOW CPU HISTORY | Displays CPU instruction history buffer in CP/M DDT format (8080 and Z80). |
| SHOW CPU HISTORY=<n> | Displays last <n> entries of the CPU instruction history buffer in CP/M DDT format (8080 and Z80). |

The BOOT EPROM card starts at address 0FF00 if it has been enabled by 'SET CPU ALTAIRROM'. Jumping to this address will boot drive 0 of the floppy controller (CPU must be set to ROM or equivalent code must be present). If no valid bootable software is present there the machine crashes. This is historically accurate behavior.

4.1.1 Registers for the 8080 and Z80

CPU registers include the following for the Z80 / 8080:

| Name | Size | Comment |
|------|------|---------|
|------|------|---------|

| | | | |
|--------|---------|---|---|
| PC | 20 | The Program Counter for the 8080 and Z80 | |
| AF | 16 | The accumulator (8 bits) and the flag register | |
| | | F = S Z - AC - P/V N C | |
| | | S | = Sign flag. |
| | | Z | = Zero Flag. |
| | | - | = not used (undefined) |
| | | AC | = Auxiliary Carry flag. |
| | | P/V | = Parity flag on 8080 (Parity / Overflow flag on Z80) |
| | | - | = not used (undefined) |
| | | N | = Internal sign flag |
| | | C | = Carry flag. |
| BC | 16 | The BC register pair. | |
| | | Register B is the high 8 bits, C is the lower 8 bits | |
| DE | 16 | The DE register pair. | |
| | | Register D is the high 8 bits, E is the lower 8 bits. | |
| HL | 16 | The HL register pair. | |
| | | Register H is the high 8 bits, L is the lower 8 bits. | |
| AF1 | 16 | The alternate AF register | (on Z80 only) |
| BC1 | 16 | The alternate BC register | (on Z80 only) |
| DE1 | 16 | The alternate DE register | (on Z80 only) |
| HL1 | 16 | The alternate HL register | (on Z80 only) |
| IX | 16 | The IX index register | (on Z80 only) |
| IY | 16 | The IY index register | (on Z80 only) |
| IFF | 8 | Interrupt flag | (on Z80 only) |
| IR | 8 | Interrupt register | (on Z80 only) |
| SR | 16 | The front panel switches (use D SR 8 for 4k Basic). | |
| WRU | 8 | The interrupt character. This starts as 5 (Control-E) but some Altair software uses this keystroke so best to change this to something exotic such as 1D (which is Control-]). But make sure you can actually create this character via the keyboard. | |
| BANK | 3 | The currently active memory bank (if banked memory is activated - see memory options above) | |
| COMMON | 16 | The starting address of common memory. Originally set to 0C000 (note this setting must agree with the value supplied to GENCPM for CP/M 3 system generation) | |
| PCQ | 16 x 64 | Circular buffer of the last 64 PC jump targets. This can be viewed with "e pcq[0-63]". | |
| PCQP | 16 | The head index of the circular buffer | |
| CLOCK | 32 | The clock speed of the simulated CPU (8080 / Z80) in kHz or 0 to run at maximum speed. To set the clock speed for a typical 4 MHz Z80 CPU, use D CLOCK 4000. The CP/M utility SPEED measures the clock speed of the simulated CPU. | |
| SLICE | 16 | The slice length in milliseconds for the clock speed simulation. The default is 10 ms. | |

| | | |
|--------------|----|---|
| TSTATES | 32 | The number of executed t-states (8080 / Z80) – read only. |
| CAPACITY | 32 | Capacity of the RAM – read only. Use the SET commands above to set the memory capacity. |
| PREVCAP | 32 | The previous capacity of the RAM – read only. |
| SWITCHERPORT | | The 8-bit port number of the CPU switcher port. The default is FD. |

4.1.2 Registers for the 8086

CPU registers include the following for the 8086:

| Name | Size | Comment |
|-------|------|--|
| AX | 16 | AX general purpose register |
| AL | 8 | low 8 bits of AX |
| AH | 8 | high 8 bits of AX |
| BX | 16 | BX general purpose register |
| BL | 8 | low 8 bits of BX |
| BH | 8 | high 8 bits of BX |
| CX | 16 | CX general purpose register |
| CL | 8 | low 8 bits of CX |
| CH | 8 | high 8 bits of CX |
| DX | 16 | DX general purpose register |
| DL | 8 | low 8 bits of DX |
| DH | 8 | high 8 bits of DX |
| BP | 16 | Base Pointer |
| SI | 16 | Source Index |
| DI | 16 | Destination Index |
| SP86 | 16 | Stack Pointer |
| CS | 16 | Code Segment |
| DS | 16 | Data Segment |
| ES | 16 | Extra Segment |
| SS | 16 | Stack Segment |
| PCX | 20 | virtual 20-bit program counter |
| SPX | 16 | Stack Pointer |
| IP | 16 | Instruction Pointer, read-only, to set use PCX which allows 20 bit addresses |
| FLAGS | 16 | Flags |

15 14 13 12 11 10 09 08 07 06 05 04 03 02 01 00
1 1 1 1 OF DF IF TF SF ZF Res. AF Res. PF 1 CF
OF = Overflow Flag
DF = Direction Flag
IF = Interrupt Flag
TF = Trace Flag
SF = Sign Flag
ZF = Zero Flag
AF = Auxiliary Carry Flag

PF = Parity Flag
 CF = Carry Flag

4.1.3 Registers for the MC68000

CPU registers include the following for the MC68000

| Name | Size | Comment |
|----------|------|---|
| M68K_D0 | 32 | D0 – general purpose data register |
| M68K_D1 | 32 | D1 – general purpose data register |
| M68K_D2 | 32 | D2 – general purpose data register |
| M68K_D3 | 32 | D3 – general purpose data register |
| M68K_D4 | 32 | D4 – general purpose data register |
| M68K_D5 | 32 | D5 – general purpose data register |
| M68K_D6 | 32 | D6 – general purpose data register |
| M68K_D7 | 32 | D7 – general purpose data register |
| M68K_A0 | 32 | A0 – general purpose address register |
| M68K_A1 | 32 | A1 – general purpose address register |
| M68K_A2 | 32 | A2 – general purpose address register |
| M68K_A3 | 32 | A3 – general purpose address register |
| M68K_A4 | 32 | A4 – general purpose address register |
| M68K_A5 | 32 | A5 – general purpose address register |
| M68K_A6 | 32 | A6 – general purpose address register |
| M68K_A7 | 32 | A7 – general purpose address register |
| M68K_PC | 32 | PC – program counter |
| M68K_SR | 32 | SR – status register |
| | | 15 14 13 12 11 10 09 08 07 06 05 04 03 02 01 00 |
| | | T1 T0 S M 0 I2 I1 I0 0 0 0 X N Z V C |
| | | T1 = Trace Enable T1 |
| | | T0 = Trace Enable T0 |
| | | S = Supervisor / User State |
| | | M = Master / Interrupt State |
| | | I2 = Interrupt Priority Mask I2 |
| | | I1 = Interrupt Priority Mask I1 |
| | | I0 = Interrupt Priority Mask I0 |
| | | X = Extend |
| | | N = Negative |
| | | Z = Zero |
| | | V = Overflow |
| | | C = Carry |
| M68K_SP | 32 | SP – stack pointer (located in A7) |
| M68K_USP | 32 | USP – user stack pointer |

| | | |
|----------------|----|--|
| M68K_ISP | 32 | ISP – interrupt stack pointer |
| M68K_MSP | 32 | MSP – master stack pointer |
| M68K_SFC | 32 | SFC – source function code register |
| M68K_DFC | 32 | DFC – destination function code register |
| M68K_VBR | 32 | VBR – vector base register |
| M68K_CACR | 32 | CACR – cache control register |
| M68K_CAAR | 32 | CAAR – cache address register |
| M68K_PREF_ADDR | 32 | last prefetch address |
| M68K_PREF_DATA | 32 | last prefetch data |
| M68K_PPC | 32 | PPC – previous value of program counter |
| M68K_IR | 32 | IR – instruction register |
| M68K_CPU_TYPE | 32 | CPU type (read only), 1 for MC68000 |

The CPU device supports the following debug flags (set with “SET CPU DEBUG=f1{;f}” or “SET CPU DEBUG” to enable all of them)

| | |
|---------|---|
| LOG_IN | Log all IN operations to the file specified with “SET DEBUG <file>” |
| LOG_OUT | Log all OUT operations to the file specified with “SET DEBUG <file>”. Use “SET NODEBUG” to close the file. Also note that there is no logging if no file has been specified. |

4.2 The Serial I/O Card (2SIO)

This simple programmed I/O device provides 2 serial ports to the outside world, which could be hardware jumpered to support RS-232 plugs or a TTY current loop interface. The standard I/O addresses assigned by MITS was 10-11 (hex) for the first port, and 12-13 (hex) for the second. We follow this standard in the simulator.

The simulator directs I/O to/from the first port to the screen. The second port reads from an attachable "tape reader" file on input, and writes to an attachable "punch file" on output. These files are considered a simple stream of 8-bit bytes.

The SIO can be configured in SIMH with the following commands:

| | |
|---------------|--|
| SET SIO ANSI | Bit 8 is set to zero on console output |
| SET SIO TTY | Bit 8 is not touched on console output |
| SET SIO ALL | Console input remain unchanged |
| SET SIO UPPER | Console input is transformed to upper case characters only (This feature is useful for most Altair software). SET SIO MAP must also have been executed for this option to take effect - otherwise no mapping occurs. |
| SET SIO BS | Map the delete character to backspace SET SIO MAP must also have been executed for this option to take effect - otherwise no mapping occurs. |
| SET SIO DEL | Map the backspace character to delete SET SIO MAP must also have been executed for this option to take effect - otherwise no mapping occurs. |
| SET SIO QUIET | Do not print warning messages |

| | |
|--|--|
| SET SIO VERBOSE | Print warning messages (useful for debugging) The register SLOWL determines how often the same warning is displayed. The default is 3. |
| SET SIO MAP | Enable mapping of characters (see also SET SIO ALL/UPPER/BS/DEL) |
| SET SIO NOMAP | Disable mapping of characters (see also SET SIO ALL/UPPER/BS/DEL) |
| SET SIO BELL | Displaying ^G (Control-G) sounds the bell |
| SET SIO NOBELL | Do not display ^G (Control-G, bell character. This feature is useful when a simulated program makes excessive use of the bell character. Furthermore, the SHOW command prints more information. |
| SET SIO INTERRUPT | Status port 0 creates an interrupt when a character becomes available. The handler is at SIO register KEYBDH. |
| SET SIO NOINTERRUPT | Status port 0 does not create interrupts. |
| SET SIO SLEEP | Sleeps for SLEEP milliseconds after a keyboard status check where no character was available. This is useful in many operating systems to avoid high real CPU usage in busy wait loops. Use "D SLEEP <n>" to change the number of milliseconds – the default value is 1. |
| SET SIO NOSLEEP | Do not sleep after unsuccessful keyboard status checks. |
| SET SIO PORT=Port/Terminal/Read/NotRead/Write/Reset/Reset/Data | <p>Port: two digit hex address of the new port</p> <p>Terminal: one digit decimal number of terminal line</p> <p>Read: two digit hex mask indicating the bit(s) set when a character is available</p> <p>NotRead: two digit hex mask indicating the bit(s) to set in case no character is available</p> <p>Write: two digit hex mask indicating the bits set when a character can be written</p> <p>Reset: T (port has reset command) or F (port has no reset command)</p> <p>Reset: two digit hex value of the reset command</p> <p>Data: T (port accepts OUT, i.e. is a data port) or F (port only has IN, i.e. is a status port).</p> |

The standard setting for the console / keyboard port is equivalent to

SET SIO PORT=10/0/1/0/2/T/3/F

SET SIO PORT=11/0/1/0/2/T/3/T

You can also attach the SIO to a port or a file:

| | |
|-----------------------|--|
| ATTACH SIO 23 | Console IO goes via a Telnet connection on port 23 (often requires root privileges, you can also use another port and use telnet with this port) |
| ATTACH SIO <filename> | Console input is taken from the file with name <filename> and output goes to the SIMH console. Note that sometimes this does not work as expected since some application programs or operating system commands periodically check for input. |
| DETACH SIO | Console IO goes via the regular SIMH console |

The SIO device supports the following debug flags (set with "SET SIO DEBUG=f1{;f}" or "SET SIO DEBUG" to enable all of them)

| | |
|---------|---|
| IN | All IN operations on the SIO ports (status and data) |
| OUT | All OUT operations on the SIO ports (status and data) |
| CMD | All OUT operations which are interpreted as commands |
| VERBOSE | All warning messages (currently: none) |

The PTP device supports the following debug flags (set with "SET PTP DEBUG=f1{;f}" or "SET PTP DEBUG" to enable all of them)

| | |
|---------|---|
| IN | All IN operations on the PTP ports (status and data) |
| OUT | All OUT operations on the PTP ports (status and data) |
| CMD | All OUT operations which are interpreted as commands |
| VERBOSE | All warning messages (currently: use of unattached PTP) |

The PTR device supports the following debug flags (set with "SET PTR DEBUG=f1{;f}" or "SET PTR DEBUG" to enable all of them)

| | |
|---------|--|
| IN | All IN operations on the PTR ports (status and data) |
| OUT | All OUT operations on the PTR ports (status and data) |
| CMD | All OUT operations which are interpreted as commands |
| VERBOSE | All warning messages (currently: use of unattached PTR, attempt to read past end of attached file) |

4.3 MITS 88-2SIO Serial Adapter (M2SIO)

This M2SIO device provides an alternative to the SIO device for serial communications. The M2SIO device provides two independent MITS 88-2SIO serial ports, M2SIO0 and M2SIO1, with full support for attaching to sockets and host serial ports.

By default, the M2SIO0 port directs I/O to/from the screen and keyboard. The second port also directs its output to the screen. The default I/O base port for M2SIO0 is 10H and M2SIO1 is 12H.

Unlike the SIO device, the M2SIO device provides raw ports, meaning data is sent and received as is without any translation or other manipulations. Also, there are no PTP or PTR devices.

Before either of these ports can be used, they must be enabled:

| | |
|----------------|---|
| SET M2SIO0 ENA | Enable the first 88-2SIO port (replaces SIO port) |
| SET M2SIO1 ENA | Enable the second 88-2SIO port (replaces PTP and PTR ports) |

Once enabled, the M2SIO ports can be configured in SIMH with the following commands, where 'x' is 0 for port 0 and 1 for port 1:

| | |
|----------------------|---------------------------------------|
| SET M2SIOx IOBASE | Sets MITS 2SIO base I/O address |
| SET M2SIOx CONSOLE | Port checks console for input |
| SET M2SIOx NOCONSOLE | Port does not check console for input |
| SET M2SIOx DTR | DTR follows RTS |
| SET M2SIOx NODTR | DTR does not follow RTS (default) |
| SET M2SIOx DCD | Force DCD active low |
| SET M2SIOx NODCD | DCD follows status line (default) |
| SET M2SIOx BAUD=val | Set baud rate (default=9600) |
| SET M2SIOx DEBUG | Enables debugging for device M2SIOx |
| SET M2SIOx NODEBUG | Disables debugging for device M2SIOx |

The M2SIO device implements these registers:

| Name | Size | Comment |
|--------|------|------------------------------|
| M2STAx | 8 | 2SIO port x status register |
| M2CTLx | 8 | 2SIO port x control register |

| | | |
|---------|----|---------------------------------------|
| M2RXDx | 8 | 2SIO port x rx data buffer |
| M2TXDx | 8 | 2SIO port x tx data buffer |
| M2TXPx | 8 | 2SIO port x tx data pending |
| M2CONx | 1 | 2SIO port x connection status |
| M2RIEx | 1 | 2SIO port x receive interrupt enable |
| M2TIEx | 1 | 2SIO port x transmit interrupt enable |
| M2RTSx | 1 | 2SIO port x RTS status (active low) |
| M2RDRFx | 1 | 2SIO port x RDRF status |
| M2TDREx | 1 | 2SIO port x TDRE status |
| M2DCDx | 1 | 2SIO port x DCD status (active low) |
| M2CTSx | 1 | 2SIO port x CTS status (active low) |
| M2OVRNx | 1 | 2SIO port x OVRN status |
| M2WAITx | 32 | 2SIO port x wait cycles |

4.3.1 Using the M2SIO device with serial ports

It is possible to attach host serial ports to the M2SIO ports using the “Attach” command. The following example shows how to attach the second 88-2SIO port (M2SIO1) to a serial port to on a UNIX-type platform:

```
sim> set m2sio1 enable
sim> attach m2sio1 connect=/dev/cu.USA19H14411P1.1
```

The 88-2SIO does not have a DTR modem output. If you need DTR, configure the port to have DTR follow RTS with the “set m2siox dtr” command.

The 88-2SIO will not enable the receiver unless DCD is present. If you need the port to receive without DCD, configure the port to force DCD to an active low state with the “set m2siox dcd” command.

The 88-2SIO will not enable the transmitter unless RTS is active which your software should do.

4.3.2 Using the M2SIO device with sockets

The M2SIO devices may also be attached to sockets. The following example show how to attach the second 88-2SIO port to a socket listening on port 8800:

```
sim> set m2sio1 enable ;Enable M2SIO1 device
sim> set m2sio1 dtr ;TMXR sockets require DTR
sim> attach m2sio1 -U :8800 ;Bind to all interfaces on port 8800
```

Now that the simulator is listening on port 8800, you may connect to the simulator’s 88-2SIO port with “telnet <ip address> 8800”, where <ip address> is the IP address of your computer.

4.3.3 M2SIO limitations

The CP/M utilities R.COM and W.COM use the PTP and PTR devices to transfer files between the simulator and host file system. If the M2SIO1 device is enabled using the default 12H port address, these utilities will no longer work as the M2SIO1 device replaces the PTP and PTR devices.

The M2SIO device makes it possible to run communications software for CP/M, such as PCGET/PUT, MEX, MODEM 7, and BYE using host serial ports and sockets. Many of these programs use loops for timeout processing. For these timeouts to work properly, it is necessary to use the "Clock" register to simulate your CPU's speed.

4.4 The SIMH pseudo device

The SIMH pseudo device facilitates the communication between the simulated ALTAIR and the simulator environment. This device defines a number of (most R/O) registers (see source code) which are primarily useful for debugging purposes.

The SIMH pseudo device can be configured with

| | |
|-------------------|------------------------------------|
| SET SIMH TIMERON | Start periodic timer interrupts |
| SET SIMH TIMEROFF | Stop the periodic timer interrupts |

The following variables determine the behavior of the timer:

| | |
|------|--|
| TIMD | This is the delay between consecutive interrupts in milliseconds. Use D TIMD 20 for a 50 Hz clock. |
| TIMH | This is the address of the interrupt handler to call for a timer interrupt. |

The SIMH device supports the following debug flags (set with "SET SIMH DEBUG=f1{;f}" or "SET SIMH DEBUG" to enable all of them)

| | |
|---------|-------------------------------------|
| IN | All IN operations on the SIMH port |
| OUT | All OUT operations on the SIMH port |
| CMD | All illegal commands |
| VERBOSE | All other warning or error messages |

4.5 The 88-DISK controller

The MITS 88-DISK is a simple programmed I/O interface to the MITS 8-inch floppy drive, which was basically a Pertec FD-400 with a power supply and buffer board built-in. The controller supports neither interrupts nor DMA, so floppy access required the sustained attention of the CPU. The standard I/O addresses were 8, 9, and 0A (hex), and we follow the standard. Details on controlling this hardware are in the altairz80_dsk.c source file.

The only difference is that the simulated disks may be larger than the original ones: The original disk had 77 tracks while the simulated disks support up to 254 tracks (only relevant for CP/M). You can change the number of tracks per disk by setting the appropriate value in TRACKS[.]. For example "D TRACKS[0] 77" sets the number of tracks for disk 0 to the original number of 77. The command "D TRACKS[0-7] 77" changes the highest track number for all disks to 77. The Mini-Disk support was added by Mike Douglas in May 2014.

The DSK device can be configured with

| | |
|-------------------|---|
| SET DSK<n> WRTENB | Allow write operations for disk <n>. |
| SET DSK<n> WRTLCK | Disk <n> is locked, i.e. no write operations will be allowed. |

The DSK device supports the following debug flags (set with “SET DSK DEBUG=f1{;f}” or “SET DSK DEBUG” to enable all of them)

| | |
|--------------|--|
| IN | All IN operations on the controller port |
| OUT | All OUT operations on the controller port |
| READ | All read operations of the disk |
| WRITE | All write operations on the disk |
| SECTOR_STUCK | Warn when the controller appears to be stuck searching for a sector |
| TRACK_STUCK | Warn when the controller appears to be stuck searching for a track |
| VERBOSE | All other warning and error messages (e.g. disk is write locked, disk is not attached) |

4.6 The 88-HDSK controller

The 88-HDSK from MITS/Pertec consists of a 5mb removable platter and a fixed 5mb platter. Each platter is double sided. Head 0 and 1 are the top and bottom surface of the removable platter and head 2 and 3 are the top and bottom surface of the fixed platter. Hard disk BASIC treats the two platters as two separate drives. Each platter has 406 cylinders with 24 sectors per track and 256 bytes per sector.

The disk image file starts with head 0, track 0, sector 0 (0,0,0) through (0,0,23), followed by head 1, track 0, sector 0 (1,0,0) through (1,0,23). The pattern then repeats starting with (0,1,0). The external hard disk is accessed through eight ports of a 4-PIO card at I/O addresses A0h-A7h. The module was written by Mike Douglas in March 2014 and the disk images were provided by Martin Eberhard.

The MHDSK device can be configured with

| | |
|----------------------|--|
| SET MHDSK <n> WRTENB | Allow write operations for hard disk <n>. |
| SET MHDSK <n> WRTLCK | Hard disk <n> is locked, i.e. no write operations will be allowed. |

The MHDSK device supports the following debug flags (set with “SET MHDSK DEBUG=f1{;f}” or “SET MHDSK DEBUG” to enable all of them)

| | |
|---------|----------------------------------|
| READ | All read operations of the disk |
| WRITE | All write operations on the disk |
| VERBOSE | All other operations of the disk |

4.7 The simulated hard disk

In order to increase the available storage capacity, the simulator features 8 simulated hard disks with a capacity of 8MB (HDSK0 to HDSK7). Currently only CP/M supports two hard disks as devices I: and J:.

The HDSK device can be configured with

| | |
|--------------------|--|
| SET HDSK<n> WRTENB | Allow write operations for hard disk <n>. |
| SET HDSK<n> WRTLCK | Hard disk <n> is locked, i.e. no write operations will be allowed. |

SET HDSK<n> FORMAT=<value> Set the hard disk to <value>. Possible values are

- HDSK (standard simulated AltairZ80 hard disk with 8'192 kB capacity)
- CPM68K (simulated hard drive 16'384 kB capacity for CP/M-68K)
- EZ80FL (128 kB flash)

- P112 (1'440 kB P112)
- SU720 (720 kB Super I/O)
- OSB1 (100 kB Osborne 1 5.25" Single Side Single Density)
- OSB2 (200 kB Osborne 1 5.25" Single Side Dual Density)
- NSSS1 (175 kB Northstar Single Side Dual Density Format 1)
- NSSS2 (175 kB Northstar Single Side Dual Density Format 2)
- NSDS2 (350 kB Northstar Dual Side Dual Density Format 2)
- VGSS (308 kB Vector Single Side Single Density)
- VGDS (616 kB Vector Dual Side Single Density)
- DISK1A (616 kB CompuPro Disk1A Single Side Single Density)
- SSSD8 (standard 8" Single Side Single Density floppy disk with 77 tracks of 26 sectors with 128 bytes, i.e. 256 kB capacity, no skew)
- SSSD8S (standard 8" Single Side Single Density floppy disk with 77 tracks of 26 sectors with 128 bytes, i.e. 256 kB capacity, standard skew factor 6)
- SSDD8 (standard 8" Single Side Double Density floppy disk with 77 tracks of 26 sectors with 256 bytes, i.e. 512 kB capacity, no skew)
- SSDD8S (standard 8" Single Side Double Density floppy disk with 77 tracks of 26 sectors with 256 bytes, i.e. 512 kB capacity, standard skew factor 6)
- DSDD8 (standard 8" Double Side Double Density floppy disk with 77 tracks of 26 sectors with 512 bytes, i.e. 1'025 kB capacity, no skew)
- DSDD8S (standard 8" Double Side Double Density floppy disk with 77 tracks of 26 sectors with 512 bytes, i.e. 1'025 kB capacity, standard skew factor 6)
- 512SSDD8 (standard 8" Single Side Double Density floppy disk with 77 tracks of 15 sectors with 512 bytes, i.e. 591 kB capacity, no skew)
- 512DSDD8 (standard 8" Double Side Double Density floppy disk with 77 tracks of 15 sectors with 512 bytes, i.e. 1'183 kB capacity, no skew)
- APPLE-DO (140 kB, Apple II, DOS 3.3)
- APPLE-PO (140 kB, Apple II, PRODOS)
- APPLE-D2 (140 kB, Apple II, DOS 3.3, 128 byte sectors for CP/M 2)
- APPLE-P2 (140 kB, Apple II, PRODOS, 128 byte sectors for CP/M 2)
- MITS (308 kB Altair standard disk with skew)
- MITS2 (1'016 kB Altair extended disk with skew)
- V1050 (410 kB, Visual Technology Visual 1050, 512 byte sectors for CP/M 3)
- Note₁: The CP/M 3 implementation that comes with AltairZ80 automatically adapts to the attached hard disk. It supports sector sizes of 128 bytes, 256 bytes and 512 bytes.
- Note₂: The CP/M 2 implementation that comes with AltairZ80 can also adapt to all hard disk formats with 128 byte sectors. You need to set the correct format with this command after attaching a file.
- Note₃: When attaching a file to a hard disk, the format is guessed based on the size of the file. In case there is more than one possibility you may need to change the format after attaching.

SET HDSK<n> GEOM=<t>/<s>/<l> Set the hard disk geometry to <t> tracks with <s> sectors with sector length <l>. Alternatively you can also use GEOM=T:<t>/N:<s>/S:<s>.

Note that the “Attach” command will choose the correct format based on the size of the attached file. In case the file does not yet exist it is created and the HDSK format will be used with the currently set capacity.

The HDSK device supports the following debug flags (set with “SET HDSK DEBUG=f1{;f}” or “SET HDSK DEBUG” to enable all of them)

| | |
|---------|--|
| READ | All read operations of the disk |
| WRITE | All write operations on the disk |
| VERBOSE | All other warning and error messages (e.g. disk is write locked, disk is not attached) |

4.8 The simulated network

The simulator supports networking via sockets (TCP/IP) for simulating operating systems such as CP/NET (see section 5.4) and CPNOS (see section 5.5) which require at least two machines connected by a network.

The NET device can be configured with

| | |
|-----------------------------|---|
| SET NET CLIENT | Puts this machine into client mode. |
| SET NET SERVER | Puts this machine into server mode. |
| ATTACH NET <IP-addr>:<port> | Attaches the machine to the given IP address and listening on the specified port. The IP address is given in a.b.c.d format ($0 \leq a, b, c, d \leq 255$). A typical example is “ATTACH NET 127.0.0.1:4000” which attaches to the local host at port 4000. Note that certain “small” port numbers might require special permissions. |
| DETACH NET | Detaches the machine from the network. |

The NET device supports the following debug flags (set with “SET NET DEBUG=f1{;f}” or “SET NET DEBUG” to enable all of them)

| | |
|--------|--|
| ACCEPT | Show a message when a connection is accepted |
| DROP | Show a message when a connection is dropped |
| IN | Show all data received from the network |
| OUT | Show all data transmitted to the network |

5 Sample Software

Running an Altair in 1977 you would be running either MITS Disk Extended BASIC, or the brand new and sexy CP/M Operating System from Digital Research. Or possibly, you ordered Altair DOS back when it was promised in 1975, and are still waiting for it to be delivered in early 1977.

We have samples of all three for you to check out. We can't go into the details of how they work, but we'll give you a few hints.

5.1 CP/M Version 2.2

This version is my own port of the standard CP/M to the Altair. There were some "official" versions but I don't have them. None were endorsed or sold by MITS to my knowledge, however.

To boot CP/M:

```
sim> attach dsk cpm2.dsk
sim> boot dsk
```

CP/M feels like DOS, sort of. DIR will work. I have included all the standard CP/M utilities, plus a few common public-domain ones. I also include the sources to the customized BIOS and some other small programs. TYPE will print an ASCII file. DUMP will dump a binary one. LS is a better DIR than DIR. ASM will assemble .ASM files to hex, LOAD will "load" them to binary format (.COM). ED is a simple editor, #A command will bring the source file to the buffer, T command will "type" lines, L will move lines, E exits the editor. 20L20T will move down 20 lines, and type 20. Very DECish. DDT is the debugger, DO is a batch-type command processor. A sample batch file that will assemble and write out the bootable CP/M image (on drive A) is "SYSCPM2.SUB". To run it, type "DO SYSCPM2".

In order to efficiently transfer files into the CP/M environment use the included program R <filename.ext>. If you have a file named foo.ext in the current directory (i.e. the directory where SIMH is), executing R FOO.EXT under CP/M will transfer the file onto the CP/M disk. Transferring a file from the CP/M environment to the SIMH environment is accomplished by W <filename.ext> for text files or by W <filename.ext> B for binary files. The simplest way for transferring multiple files is to create a ".SUB" batch file which contains the necessary R resp. W commands.

If you need more storage space you can use a simulated hard disk on drives I: and J:. To use do "attach HDSK0 hdi.dsk" and issue the "XFORMAT I:" resp. "XFORMAT J:" command from CP/M do initialize the disk to an empty state.

The disk "cpm2.dsk" contains the following files:

| Name | Ext | Size | Comment |
|---------|------|------|---|
| ASM | .COM | 8K | CP/M assembler |
| BDOS | .MAC | 66K | Basic Disk Operating System assembler source code |
| BOOT | .COM | 2K | transfer control to boot ROM |
| BOOT | .MAC | 2K | source for BOOT.COM |
| BOOTGEN | .COM | 2K | put a program on the boot sectors |
| CBIOSEX | .MAC | 48K | CP/M 2 BIOS source for Altair |
| CCP | .MAC | 26K | Console Command Processor assembler source code, original Digital Research |
| CCPZ | .MAC | 50K | Console Command Processor assembler source code, Z80 replacement with some extra features |
| CCPZ | .TXT | 40K | documentation for CCPZ |
| CFGCCP | .LIB | 2K | configuration file for system generation, original CCP |
| CFGCCPZ | .LIB | 2K | configuration file for system generation, with CCPZ |
| COPY | .COM | 2K | copy disks |
| CPU | .COM | 2K | get and set the CPU type (8080 or Z80) |

| Name | Ext | Size | Comment |
|----------|------|------|--|
| CPU | .MAC | 2K | source for CPU.COM |
| CREF80 | .COM | 4K | cross reference utility |
| DDT | .COM | 6K | 8080 debugger |
| DDTZ | .COM | 10K | Z80 debugger |
| DIF | .COM | 4K | determine differences between two files |
| DO | .COM | 4K | batch processing with SuperSub (SUBMIT.COM replacement) |
| DSKBOOT | .MAC | 8K | source for boot ROM |
| DUMP | .COM | 2K | hex dump a file |
| ED | .COM | 8K | line editor |
| ELIZA | .BAS | 10K | Eliza game in Basic |
| EX | .MAC | 48K | source for EX8080.COM, EXZ80DOC.COM, EXZ80ALL.COM |
| EX | .SUB | 2K | benchmark execution of EX8080.COM,EXZ80DOC.COM,EXZ80ALL.COM |
| EX8080 | .COM | 12K | exercise 8080 instruction set |
| EXZ80ALL | .COM | 12K | exercise Z80 instruction set, undefined status bits taken into account |
| EXZ80DOC | .COM | 12K | exercise Z80 instruction set, no undefined status bits taken into account |
| FORMAT | .COM | 2K | format disks |
| GO | .COM | 0K | start the currently loaded program at 100H |
| HALT | .COM | 2K | execute the HALT operation for returning to the sim> command prompt – useful as the last command in a script |
| HDSKBOOT | .MAC | 6K | boot code for hard disk |
| L80 | .COM | 12K | Microsoft linker |
| LADDER | .COM | 40K | game |
| LADDER | .DAT | 2K | high score file for LADDER.COM |
| LIB80 | .COM | 6K | library utility |
| LOAD | .COM | 2K | load hex files |
| LS | .COM | 4K | directory utility |
| LU | .COM | 20K | library utility |
| M80 | .COM | 20K | Microsoft macro assembler |
| MBASIC | .COM | 24K | Microsoft Basic interpreter |
| MC | .SUB | 2K | assemble and link an assembler program |
| MCC | .SUB | 2K | read, assemble and link an assembler program |
| MCCL | .SUB | 2K | assemble, link and produce listing |
| MOVER | .MAC | 2K | moves operating system in place |
| OTHELLO | .COM | 12K | Othello (Reversi) game |

| Name | Ext | Size | Comment |
|----------|------|------|--|
| PIP | .COM | 8K | Peripheral Interchange Program |
| PRELIM | .COM | 2K | preliminary CPU tests |
| PRELIM | .MAC | 6K | source code for PRELIM.COM |
| R | .COM | 4K | read files from SIMH environment. Supports wild card expansion on UNIX and Windows for reading multiple files. |
| RSETSIMH | .COM | 2K | reset SIMH interface |
| RSETSIMH | .MAC | 2K | assembler source for RSETSIMH.COM |
| SHOWSEC | .COM | 2K | show sectors on a disk |
| SID | .COM | 8K | debugger for 8080 |
| SPEED | .COM | 2K | utility to measure the clock speed of the simulated CPU |
| STAT | .COM | 6K | provide information about currently logged disks |
| SUBMIT | .COM | 2K | batch processing |
| SURVEY | .COM | 2K | system survey |
| SURVEY | .MAC | 16K | assembler source for SURVEY.COM |
| SYSCOPY | .COM | 2K | copy system tracks between disks |
| SYSCPM2 | .SUB | 2K | create CP/M 2 on drive A:, Digital Research CCP and BDOS |
| SYSCPM2Z | .SUB | 2K | Create CP/M 2 on drive A:, CCPZ and Digital Research BDOS |
| TIMER | .COM | 2K | perform various timer operations |
| TIMER | .MAC | 2K | source code for TIMER.COM |
| UNCR | .COM | 8K | un-crunch utility |
| UNERA | .COM | 2K | un-erase a file |
| UNERA | .MAC | 16K | source for UNERA.COM |
| USQ | .COM | 2K | un-squeeze utility |
| W | .COM | 2K | write files to SIMH environment. Supports CP/M wild card expansion for writing multiple files. |
| WM | .COM | 12K | word master screen editor |
| WM | .HLP | 4K | help file for WM.COM |
| WORM | .COM | 4K | worm game for VT100 terminal |
| XFORMAT | .COM | 2K | initialize a drive (floppy or hard disk) |
| XSUB | .COM | 2K | support for DO.COM |
| ZAP | .COM | 10K | SuperZap 5.2 disk editor configured for VT100 |
| ZSID | .COM | 10K | debugger for Z80 |
| ZTRAN4 | .COM | 4K | translate 8080 mnemonics into Z80 equivalents |

5.2 CP/M Version 3 with banked memory

CP/M 3 is the successor to CP/M 2.2. A customized BIOS (BIOS3.MAC) is included to facilitate modification if so desired. The defaults supplied in GENCPM.DAT for system generation can be used. BOOTGEN.COM is used to place the CP/M loader (LDR.COM) on the boot tracks of a disk.

Running CP/M 3 with banked memory:

```
sim> attach dsk cpm3.dsk
sim> reset cpu
sim> set cpu banked
sim> set cpu itrap
sim> boot dsk
```

Executing "DO SYSCPM3" will re-generate the banked version of CP/M 3. You can boot CP/M 3 with or without a Z80 CPU. The Z80 CPU is needed for both sysgens due to the use of BOOTGEN.COM which requires it.

The disk "cpm3.dsk" contains the following files:

| Name | Ext | Size | Comment |
|----------|------|------|--|
| ASM | .COM | 8K | CP/M assembler |
| ASSIGN | .SYS | 2K | |
| BDOS3 | .SPR | 10K | |
| BIOS3 | .MAC | 28K | CP/M 3 BIOS source for Altair SIMH |
| BIOS3 | .SPR | 4K | |
| BNKBDOS3 | .SPR | 14K | |
| BNKBIOS3 | .SPR | 4K | |
| BOOT | .COM | 2K | transfer control to boot ROM |
| BOOTGEN | .COM | 2K | put a program on the boot sectors |
| CCP | .COM | 4K | |
| COPYSYS | .COM | 2K | |
| CPM3 | .SYS | 18K | |
| CPMLDR | .MAC | 38K | CP/M 3 loader assembler source |
| DATE | .COM | 4K | date utility |
| DDT | .COM | 6K | 8080 debugger |
| DDTZ | .COM | 10K | Z80 debugger |
| DEFS | .LIB | 2K | include file for BIOS3.MAC to create banked CP/M 3 |
| DEVICE | .COM | 8K | |
| DIF | .COM | 4K | determine differences between two files |
| DIR | .COM | 16K | directory utility |
| DO | .COM | 6K | batch processing (SUBMIT.COM) |
| DUMP | .COM | 2K | |

| Name | Ext | Size | Comment |
|----------|------|------|--|
| ED | .COM | 10K | |
| ERASE | .COM | 4K | |
| GENCOM | .COM | 16K | |
| GENCPM | .COM | 22K | |
| GENCPM | .DAT | 4K | CP/M generation information for banked version |
| GENCPMNB | .DAT | 4K | CP/M generation information for non-banked version |
| GET | .COM | 8K | |
| HELP | .COM | 8K | help utility |
| HELP | .HLP | 62K | help files |
| HEXCOM | .CPM | 2K | |
| HIST | .UTL | 2K | |
| INITDIR | .COM | 32K | |
| L80 | .COM | 12K | Microsoft linker |
| LDR | .COM | 4K | CP/M loader with optimized loader BIOS |
| LDRBIOS3 | .MAC | 14K | optimized (for space) loader BIOS |
| LIB | .COM | 8K | Digital Research librarian |
| LINK | .COM | 16K | Digital Research linker |
| LOAD | .COM | 2K | |
| M80 | .COM | 20K | Microsoft macro assembler |
| MC | .SUB | 2K | assemble and link an assembler program |
| MCC | .SUB | 2K | read, assemble and link an assembler program |
| PATCH | .COM | 4K | |
| PIP | .COM | 10K | Peripheral Interchange Program |
| PROFILE | .SUB | 2K | commands to be executed at start up |
| PUT | .COM | 8K | |
| R | .COM | 4K | read files from SIMH environment |
| RENAME | .COM | 4K | |
| RESBDOS3 | .SPR | 2K | |
| RMAC | .COM | 14K | Digital Research macro assembler |
| RSETSIMH | .COM | 2K | reset SIMH interface |
| SAVE | .COM | 2K | |
| SCB | .MAC | 2K | |
| SET | .COM | 12K | |
| SETDEF | .COM | 6K | |

| Name | Ext | Size | Comment |
|---------|------|------|----------------------------------|
| SHOW | .COM | 10K | |
| SHOWSEC | .COM | 4K | show sectors on a disk |
| SID | .COM | 8K | 8080 debugger |
| SUBMIT | COM | 6K | batch processing |
| SYSCOPY | .COM | 2K | copy system tracks between disks |
| SYSCPM3 | .SUB | 2K | create banked CP/M 3 system |
| TRACE | .UTL | 2K | |
| TSHOW | .COM | 2K | show split time |
| TSTART | .COM | 2K | create timer and start it |
| TSTOP | .COM | 2K | show final time and stop timer |
| TYPE | .COM | 4K | |
| UNERA | .COM | 2K | un-erase a file |
| W | .COM | 4K | write files to SIMH environment |
| XREF | .COM | 16K | cross reference utility |
| ZSID | .COM | 10K | Z80 debugger |

5.3 MP/M II with banked memory

MP/M II is an acronym for MultiProgramming Monitor Control Program for Microprocessors. It is a multi-user operating system for an eight bit microcomputer. MP/M II supports multiprogramming at each terminal. This version supports four terminals available via Telnet. To boot:

```
sim> attach dsk mpm.dsk
sim> set cpu itrapp
sim> set cpu z80
sim> set cpu altairrom
sim> set cpu banked
sim> attach sio 23
sim> d common b000
sim> boot dsk
```

Now connect a Telnet session to the simulator and type "MPM" at the "A>" prompt. Now you can connect up to three additional terminals via Telnet to the Altair running MP/M II. To re-generate the system perform "DO SYSPPM" in the CP/M environment (not possible under MP/M since XSUB is needed).

The disk "mpm.dsk" contains the following files:

| Name | Ext | Size | Comment |
|-------|------|------|-----------------|
| ABORT | .PRL | 2K | abort a process |
| ABORT | .RSP | 2K | |
| ASM | .PRL | 10K | MP/M assembler |

| Name | Ext | Size | Comment |
|----------|------|------|--|
| BNKBDOS | .SPR | 12K | banked BDOS |
| BNKXDOS | .SPR | 2K | banked XDOS |
| BNKXIOS | .SPR | 4K | banked XIOS |
| BOOTGEN | .COM | 2K | copy an executable to the boot section |
| CONSOLE | .PRL | 2K | print console number |
| CPM | .COM | 2K | return to CP/M |
| CPM | .MAC | 2K | source for CPM.COM |
| DDT | .COM | 6K | MP/M DDT |
| DDT2 | .COM | 6K | CP/M DDT |
| DDTZ | .COM | 10K | CP/M DDT with Z80 support |
| DIF | .COM | 4K | difference between two files |
| DIR | .PRL | 2K | directory command |
| DO | .COM | 2K | batch processing (SUBMIT.COM) |
| DSKRESET | .PRL | 2K | disk reset command |
| DUMP | .MAC | 6K | source for DUMP.PRL |
| DUMP | .PRL | 2K | dump command |
| ED | .PRL | 10K | MP/M line editor |
| ERA | .PRL | 2K | erase command |
| ERAQ | .PRL | 4K | erase command (verbose) |
| GENHEX | .COM | 2K | |
| GENMOD | .COM | 2K | |
| GENSYS | .COM | 10K | |
| L80 | .COM | 12K | Microsoft linker |
| LDRBIOS | .MAC | 14K | loader BIOS |
| LIB | .COM | 8K | library utility |
| LINK | .COM | 16K | linker |
| LOAD | .COM | 2K | loader |
| M80 | .COM | 20K | Microsoft macro assembler |
| MC | .SUB | 2K | assemble and link an assembler program |
| MCC | .SUB | 2K | read, assemble and link an assembler program |
| MPM | .COM | 8K | start MP/M II |
| MPM | .SYS | 26K | MP/M system file |
| MPMD | .LIB | 2K | define a banked system |
| MPMLDR | .COM | 6K | MP/M loader without LDRBIOS |

| Name | Ext | Size | Comment |
|----------|------|------|--|
| MPMSTAT | .BRS | 6K | status of MP/M system |
| MPMSTAT | .PRL | 6K | |
| MPMSTAT | .RSP | 2K | |
| MPMXIOS | .MAC | 26K | XIOS for MP/M |
| PIP | .PRL | 10K | MP/M peripheral interchange program |
| PIP2 | .COM | 8K | CP/M peripheral interchange program |
| PRINTER | .PRL | 2K | |
| PRLCOM | .PRL | 4K | |
| R | .COM | 4K | read a file from the SIMH environment |
| RDT | .PRL | 8K | debugger for page relocatable programs |
| REN | .PRL | 4K | rename a file |
| RESBDOS | .SPR | 4K | non-banked BDOS |
| RMAC | .COM | 14K | Digital Research macro assembler |
| RSETSIMH | .COM | 2K | reset SIMH interface |
| SCHED | .BRS | 2K | schedule a job |
| SCHED | .PRL | 4K | |
| SCHED | .RSP | 2K | |
| SDIR | .PRL | 18K | fancy directory command |
| SET | .PRL | 8K | set parameters |
| SHOW | .PRL | 8K | show status of disks |
| SPOOL | .BRS | 4K | spool utility |
| SPOOL | .PRL | 4K | |
| SPOOL | .RSP | 2K | |
| STAT | .COM | 6K | CP/M stat command |
| STAT | .PRL | 10K | MP/M stat command |
| STOPSPLR | .PRL | 2K | stop spooler |
| SUBMIT | .PRL | 6K | MP/M submit |
| SYSCOPY | .COM | 2K | copy system tracks |
| SYSMPM | .SUB | 2K | do a system generation |
| SYSTEM | .DAT | 2K | default values for system generation |
| TMP | .SPR | 2K | |
| TOD | .PRL | 4K | time of day |
| TSHOW | .COM | 2K | show split time |
| TSTART | .COM | 2K | create timer and start it |

| Name | Ext | Size | Comment |
|-------|------|------|----------------------------------|
| TSTOP | .COM | 2K | show final time and stop timer |
| TYPE | .PRL | 2K | type a file on the screen |
| USER | .PRL | 2K | set user area |
| W | .COM | 4K | write a file to SIMH environment |
| XDOS | .SPR | 10K | XDOS |
| XREF | .COM | 16K | cross reference utility |
| XSUB | .COM | 2K | for CP/M DO |

5.4 CP/NET

This software is included as part of the archive **cpnet.zip**. To bring up the server component:

```
sim> attach dsk cpnetserver.dsk
sim> d common ab00
sim> set cpu 64k
sim> set cpu itraps
sim> set cpu z80
sim> set cpu altairrom
sim> set cpu banked
sim> set simh timeroff
sim> attach sio 23
sim> set net server
sim> at net 127.0.0.1:4000
sim> boot dsk
```

You can also execute “AltairZ80 cpnetserver” for the same effect or type “do cpnetserver<return>” at the “sim>” command prompt. Then connect via Telnet (“telnet 127.0.0.1” or “telnet localhost”) to the simulator and type “mpm <return>” at the “A>” command prompt to start the MP/M CP/NET server.

To bring up a client, start another instance of AltairZ80 and type the following at the command prompt:

```
sim> attach dsk cpnetclient.dsk
sim> set cpu 64k
sim> set cpu noitraps
sim> set cpu z80
sim> set cpu altairrom
sim> set cpu nonbanked
sim> reset cpu
sim> set sio ansi
sim> set net client
sim> at net 127.0.0.1:4000
```

```
sim> boot dsk
```

You can also execute “AltairZ80 cpnetclient” for the same effect or type “do cpnetclient<return>” at the “sim>” command prompt. Then

```
A>cpnetldr<return> ; loads CP/NET client
A>login<return>    ; to login
A>network b:=a:    ; to map server drive A: to client drive B:
A>dir b:           ; shows the contents of the server drive A:
```

The MP/M server is configured to accept one or two network clients. So you can repeat the previous procedure for a second client if you wish.

Note that all system specific sources (SNIOS.MAC, NETWRKIF.MAC, MPMXIOS.MAC) are included on cpnetclient.dsk respectively cpnetserver.dsk. When executing “GENSYS” for re-creating MP/M, keep in mind to include SERVER.RSP and NETWRKIF.RSP as this is not automatically suggested by GENSYS.

5.5 CPNOS

CPNOS is a thin client front-end for the CP/NET server. This software is also included as part of the archive **cpnet.zip**. In order to execute, first bring up a CP/NET server as described in section 5.4. Then for the client, start another instance of AltairZ80:

```
sim> set cpu 64k
sim> set cpu noitrap
sim> set cpu z80
sim> set cpu noaltairrom
sim> set cpu nonbanked
sim> reset cpu
sim> set sio ansi
sim> set net client
sim> at net 127.0.0.1:4000
sim> load cpnos.com f000
sim> g f000
```

For the same effect you can also execute “AltairZ80 cpnos” or type “do cpnos<return>” at the “sim>” command prompt. At the “LOGIN=” prompt, just type return and you will see the familiar “A>” prompt but the drive is the A: drive of the MP/M CP/NET server (you can also attach other disks to the server and they will become available to the CPNOS client). You can also connect a second CPNOS client to the same CP/NET server – further connection attempts will block after logging in until another CPNOS client is disconnected (e.g. by typing ^E to stop the simulator and then typing “bye<return>” at the simh command prompt). It is also possible to have both a CP/NET client and a CPNOS thin client connect to the same CP/NET server.

Note that all system specific sources (CPBIOS.MAC and CPNIOS.MAC) are included on cpnetclient.dsk.

5.6 CP/M application software

There is also a small collection of sample application software containing the following items:

- SPL a Small Programming Language with a suite of sample programs
- PROLOGZ a Prolog interpreter written in SPL with sources

- PASCFORM a Pascal pretty printer written in Pascal
- Pascal MT+ Pascal language system needed to compile PASCFORM

The sample software comes on "app.dsk" and to use it do

```
sim> attach dsk1 app.dsk
```

before booting CP/M.

The disk "app.dsk" contains the following files:

| Name | Ext | Size | Comment |
|----------|------|------|--|
| ACKER | .COM | 2K | compute the Ackermann function |
| ACKER | .SPL | 4K | compute the Ackermann function, SPL source |
| BOOTGEN | .COM | 2K | copy the operating system to the rights sectors and tracks |
| BOOTGEN | .SPL | 6K | SPL source for BOOTGEN.COM |
| C | .SUB | 2K | batch file for compiling an SPL source file |
| CALC | .PRO | 4K | Prolog demo program: Calculator |
| DIF | .COM | 4K | |
| DIF | .SPL | 10K | SPL source for DIF.COM |
| FAC | .COM | 2K | compute the factorial |
| FAC | .SPL | 4K | compute the factorial, SPL source |
| FAMILY | .PRO | 4K | Prolog demo program: Family relations |
| FORMEL | .COM | 4K | calculator |
| FORMEL | .SPL | 6K | calculator, SPL source |
| INTEGER | .PRO | 2K | Prolog demo program: Integer arithmetic |
| KNAKE | .PRO | 2K | Prolog demo program: Logic puzzle |
| LINKMT | .COM | 12K | Pascal MT+ 5.5 linker |
| MTERRS | .TXT | 6K | Pascal MT+ error messages |
| MTPLUS | .000 | 14K | Pascal MT+ 5.5 compiler file |
| MTPLUS | .001 | 12K | Pascal MT+ 5.5 compiler file |
| MTPLUS | .002 | 8K | Pascal MT+ 5.5 compiler file |
| MTPLUS | .003 | 8K | Pascal MT+ 5.5 compiler file |
| MTPLUS | .004 | 18K | Pascal MT+ 5.5 compiler file |
| MTPLUS | .005 | 8K | Pascal MT+ 5.5 compiler file |
| MTPLUS | .006 | 6K | Pascal MT+ 5.5 compiler file |
| MTPLUS | .COM | 36K | Pascal MT+ 5.5 compiler |
| PASCFORM | .COM | 36K | Pascal formatter |
| PASCFORM | .PAS | 54K | Pascal formatter source code |
| PASCFORM | .SUB | 2K | create Pascal formatter |

| Name | Ext | Size | Comment |
|----------|------|------|--|
| PASLIB | .ERL | 24K | Pascal MT+ 5.5 run time library |
| PINST | .COM | 4K | terminal installation program for PROLOGZ |
| PINST | .SPL | 16K | terminal installation program for PROLOGZ, SPL source |
| PRIM | .COM | 2K | compute prime numbers |
| PRIM | .SPL | 2K | compute prime numbers, SPL source |
| PROLOGZ | .COM | 16K | PROLOGZ interpreter and screen editor |
| PROLOGZ | .SPL | 54K | SPL source for PROLOGZ |
| PROLOGZ | .TXT | 40K | PROLOGZ documentation in German |
| PROLOGZU | .MAC | 2K | helper functions for PROLOGZ in assembler |
| QUEEN | .PRO | 2K | Prolog demo program: N-queens problem |
| READ | .COM | 4K | transfer a file from the file system to the CP/M disk, see also WRITE.COM. Often the name of this program is abbreviated to R.COM. |
| READ | .SPL | 10K | SPL source for READ.COM |
| RELDUMP | .COM | 4K | dump a .REL file to the console |
| RELDUMP | .SPL | 10K | dump a .REL file to the console, SPL source |
| SHOWSEC | .COM | 2K | show a disk sector |
| SHOWSEC | .SPL | 6K | SPL source for SHOWSEC.COM |
| SIEVE | .COM | 2K | compute prime numbers with a sieve |
| SIEVE | .SPL | 6K | compute prime numbers with a sieve, SPL source |
| SPEED | .COM | 2K | utility to measure the clock speed of the simulated CPU |
| SPEED | .SPL | 4K | SPL source for SPEED.COM |
| SPL | .COM | 28K | the SPL compiler itself |
| SPL | .TXT | 50K | SPL language and compiler documentation |
| SPLERROR | .DAT | 8K | error messages of the compiler |
| SPLRTL | .REL | 2K | SPL runtime library |
| SYSCOPY | .COM | 2K | copy the system tracks between disks |
| SYSCOPY | .SPL | 6K | SPL source for SYSCOPY.COM |
| WC | .COM | 6K | word count and query facility |
| WC | .SPL | 14K | word count and query facility, SPL source |
| WRITE | .COM | 2K | write a CP/M file to the file system, see also READ.COM. Often the name of this program is abbreviated to W.COM. |
| WRITE | .SPL | 8K | SPL source for WRITE.COM |
| XFORMAT | .COM | 2K | format a regular disk or a hard disk |
| XFORMAT | .SPL | 6K | SPL source for XFORMAT.COM |

5.7 MITS Disk Extended BASIC Version 4.1

This was the commonly used software for serious users of the Altair computer. It is a powerful (but slow) BASIC with some extended commands to allow it to access and manage the disk. There was no operating system it ran under. This software is part of the archive **altsw.zip**. To boot:

```
sim> set cpu 8080                ;Z80 will not work
sim> attach dsk mbasic.dsk
sim> set sio upper
sim> go ff00
MEMORY SIZE? [return]
LINEPRINTER? [C return]
HIGHEST DISK NUMBER? [0 return] (0 here = 1 drive system)
NUMBER OF FILES? [3 return]
NUMBER OF RANDOM FILES? [2 return]
44041 BYTES FREE
ALTAIR BASIC REV. 4.1
[DISK EXTENDED VERSION]
COPYRIGHT 1977 BY MITS INC.
OK
[MOUNT 0]
OK
[FILES]
```

5.8 Altair DOS Version 1.0

This was long promised but not delivered until it was almost irrelevant. A short attempted tour will reveal it to be a dog, far inferior to CP/M. This software is part of the archive **altsw.zip**. To boot:

```
sim> d tracks[0-7] 77           ;set to Altair settings
sim> set cpu altairrom
sim> attach dsk altdos.dsk
sim> set sio upper
sim> go ff00
MEMORY SIZE? [return]
INTERRUPTS? N [return]
HIGHEST DISK NUMBER? [0 return] (3 here = 4 drive system)
HOW MANY DISK FILES? [3 return]
HOW MANY RANDOM FILES? [2 return]

056449 BYTES AVAILABLE
DOS MONITOR VER 1.0
```

COPYRIGHT 1977 BY MITS INC

.[MNT 0]

.[DIR 0]

5.9 Altair Basic 3.2 (4k)

In order to run the famous 4k Basic, use the following commands (the trick is to get the Switch Register right). This software is part of the archive **altsw.zip**. You can also use “altairz80 bas432” to run this version of Basic. Note that the underscore character (“_”) can be used to cancel the last character entered, i.e. “PRINT 199_8” will print 198.

```
sim> set cpu 8080      ;note 4k Basic will not run on a Z80 CPU
sim> set sio upper     ;4k Basic does not like lower case letters as input
sim> set cpu noitrap   ;4k Basic likes to execute non 8080 instructions-ignore
sim> set sio ansi      ;4k Basic produces 8-bit output, strip to seven bits
sim> d sr 8           ;good setting for the Switch Register
sim> load 4kbas32.bin;load it at 0
sim> g                ;and start it
MEMORY SIZE? [return]
TERMINAL WIDTH? [return]
WANT SIN? [Y]

61911 BYTES FREE

BASIC VERSION 3.2
[4K VERSION]

OK
```

5.10 Altair Basic 4.0 (4k)

An improved 4K Basic is also as part of the archive **altsw.zip**. You can also use “altairz80 bas440” to run this version of Basic.

```
sim> set cpu 8080      ;note 4k Basic will not run on a Z80 CPU
sim> set sio upper     ;4k Basic does not like lower case letters as input
sim> set cpu noitrap   ;4k Basic likes to execute non 8080 instructions-ignore
sim> set sio ansi      ;4k Basic produces 8-bit output, strip to seven bits
sim> d sr 8           ;good setting for the Switch Register
sim> load 4kbas40.bin;load it at 0
sim> g                ;and start it
MEMORY SIZE? [return]
```

```
TERMINAL WIDTH? [return]
WANT SIN? [Y]
61900 BYTES FREE
4K BASIC 4.0
COPYRIGHT MITS 1976
OK
```

5.11 Altair 8k Basic

Running 8k Basic follows the procedure for 4k Basic. This software is part of the archive **altsw.zip**.

```
sim> set cpu 8080      ;note 8k Basic will not run on a Z80 CPU
sim> set sio upper     ;8k Basic does not like lower case letters as input
sim> set sio ansi      ;8k Basic produces 8-bit output, strip to seven bits
sim> d sr 8            ;good setting for the Switch Register
sim> load 8kbas.bin 0   ;load it at 0
sim> go 0              ;and start it
MEMORY SIZE? [A]
```

```
WRITTEN FOR ROYALTIES BY MICRO-SOFT
```

```
MEMORY SIZE? [return]
TERMINAL WIDTH? [return]
WANT SIN-COS-TAN-ATN? [Y]
```

```
58756 BYTES FREE
ALTAIR BASIC REV. 4.0
[EIGHT-K VERSION]
COPYRIGHT 1976 BY MITS INC.
OK
```

5.12 Altair Basic 4.0

This software is part of the archive **altsw.zip**. Execute the following commands to run Altair Extended Basic:

```
sim> set sio upper     ;Extended Basic requires upper case input
sim> set sio ansi      ;Extended Basic produces 8-bit output, strip to 7 bits
sim> d sr 8            ;good setting for the Switch Register
sim> load exbas.bin 0   ;load it at 0
sim> go 0              ;and start it
16384 Bytes loaded at 0.
```

```
MEMORY SIZE? [return]
WANT SIN-COS-TAN-ATN? [Y]

50606 BYTES FREE
ALTAIR BASIC REV. 4.0
[EXTENDED VERSION]
COPYRIGHT 1977 BY MITS INC.
OK
```

5.13 Altair Disk Extended Basic Version 300-5-C

This version of Basic was provided by Scott LaBombard. This software is part of the archive **altsw.zip**. To execute use the following commands:

```
sim> d tracks[0-7] 77 ;set to Altair settings
sim> at dsk extbas5.dsk
sim> g 0
```

```
MEMORY SIZE? [return]
LINEPRINTER? [C]
HIGHEST DISK NUMBER? [0]
HOW MANY FILES? [3]
HOW MANY RANDOM FILES? [3]
```

```
42082 BYTES FREE
```

```
ALTAIR DISK EXTENDED BASIC
VERSION 300-5-C [01NOV78]
COPYRIGHT 1978 BY MITS INC.
```

```
OK
```

5.14 Altair Disk Extended Basic Version 5.0

This version of Basic can be found on Andrew Kessel's <http://www.altairage.com/> site. Note that the MBL files on this site need to be converted to plain binary files using the Python script in the appendix. This software is part of the archive **altsw.zip**. To execute use the following commands:

```
sim> d tracks[0-7] 77 ;set to Altair settings
sim> at dsk disbas50.dsk
sim> d sr 8
```

```
sim> load disbas50.bin 0
sim> g 0

MEMORY SIZE? [return]
LINEPRINTER? [C]
HIGHEST DISK NUMBER? [return]
HOW MANY FILES? [3]
HOW MANY RANDOM FILES? [3]

41695 BYTES FREE
ALTAIR BASIC 5.0 [14JUL78]
[DISK EXTENDED VERSION]
COPYRIGHT 1978 BY MITS INC.
OK
```

5.15 Altair Hard Disk Basic 300-5-C

This version of Basic was provided by Martin Eberhard and uses the MHDSK device contributed by Mike Douglas. This software is part of the archive **althdsw.zip**. To execute use the following commands or type “AltairZ80 hdbasic” in a command shell.

```
sim> set sio ansi
sim> set sio nobell ;avoid problems with accounting software
sim> attach mhds0 hdbasic-300-5-c-acct.dsk
sim> attach mhds1 hdbasic-300-5-f.dsk
sim> attach dsk0 fdbasic-300-5-f.dsk ;floppy disk for copying
sim> boot mhdsk
```

```
HDBL 1.01
LOADING
MEMORY SIZE? [return]
LINEPRINTER? [C]
HIGHEST DISK NUMBER? [2]
HOW MANY FILES? [4]
CURRENT DAY? [4]
CURRENT MONTH? [4]
CURRENT YEAR? [88]

32762 BYTES FREE
ALTAIR HARD DISK BASIC
```

VERSION 300-5-C [02NOV78]

COPYRIGHT 1978 BY MITS INC.

OK

5.16 Altair programming languages VTL-2 and MINOL

Emmanuel ROCHE retyped the manuals and assembler code for these two tiny languages. You need the archive **minolvtl.zip** which contains full documentation, sources and command files to execute the simulator.

5.17 UCSD Pascal II.0

The software is part of the **ucsd.zip** archive. To run it, type `altairz80 ucsd` at your command prompt or alternatively invoke `altairz80` and type "do ucsd" at the "sim>" command prompt.

Useful hints:

- ? shows additional commands.
- V shows online volumes in the Filer.
- ":" denotes the prefixed volume.
- Compiling the compiler and similar tools: Attach the correct disk and set the prefix to the name of the mounted volume. Then the include files will be found.
- To invoke the Basic compiler rename `SYSTEM.COMPILER` to `PASCAL.COMPILER` and then rename `BASIC.COMPILER` to `SYSTEM.COMPILER`.
- If you get "Please re-boot" after crunching a disk: type ^E, "g 0" and "pascal" to restart the system.

DSK0 contains a fairly complete development system with Pascal, Assembler and Basic.

```
Filer: G(et, S(ave, W(hat, N(ew, L(dir, R(em, C(hng, T(rans, D(ate, Q(uit [B]
```

```
DSK0:
```

| | | | | | |
|-----------------|----|-----------|-----|-----|----------|
| SYSTEM.MICRO | 19 | 9-Feb-79 | 10 | 512 | Datafile |
| SYSTEM.FILER | 28 | 10-Apr-79 | 29 | 512 | Codefile |
| SYSTEM.EDITOR | 45 | 10-Feb-79 | 57 | 512 | Codefile |
| SYSTEM.LINKER | 22 | 10-Feb-79 | 102 | 512 | Codefile |
| SYSTEM.COMPILER | 68 | 8-Feb-79 | 124 | 512 | Codefile |
| SYSTEM.SYNTAX | 14 | 2-May-79 | 192 | 512 | Textfile |
| SETUP.CODE | 25 | 14-May-79 | 206 | 512 | Codefile |
| BINDER.CODE | 6 | 3-May-79 | 231 | 512 | Codefile |
| SYSTEM.MISCINFO | 1 | 10-Feb-79 | 237 | 192 | Datafile |
| VT100GOTO.TEXT | 4 | 10-Apr-79 | 238 | 512 | Textfile |
| VT100GOTO.CODE | 2 | 10-Apr-79 | 242 | 512 | Codefile |
| SYSTEM.PASCAL | 33 | 10-Apr-79 | 244 | 512 | Datafile |
| SYSTEM.LIBRARY | 17 | 10-Apr-79 | 277 | 512 | Datafile |
| BASIC.COMPILER | 30 | 11-Apr-79 | 294 | 512 | Codefile |
| LOOP.TEXT | 4 | 10-Apr-79 | 324 | 512 | Textfile |
| LOOP.CODE | 4 | 10-Apr-79 | 328 | 512 | Codefile |
| Z80.ERRORS | 8 | 28-Mar-79 | 332 | 70 | Datafile |
| Z80.OPCODES | 3 | 20-Dec-78 | 340 | 68 | Datafile |
| SYSTEM.ASSMBLER | 53 | 13-Apr-79 | 343 | 512 | Codefile |
| < UNUSED > | 98 | | 396 | | |

```
19/19 files<listed/in-dir>, 396 blocks used, 98 unused, 98 in largest
```

5.18 CP/M-68K

The software is part of the **cpm68k.zip** archive. To run it, type “altairz80 cpm68k” at your command prompt or alternatively invoke altairz80 and type “do cpm68k” at the “sim>” command prompt.

6 Special simulator features

6.1 Memory access breakpoints (8080/Z80 only)

In addition to the regular SIMH features such as PC queue, breakpoints etc., this simulator supports memory access breakpoints. A memory access breakpoint is triggered when a pre-defined memory location is accessed (read, write or update). To set a memory location breakpoint enter

```
sim> break -m <location>
```

Execution will stop whenever an operation accesses <location>. Note that a memory access breakpoint is not triggered by fetching code from memory (this is the job of regular breakpoints). This feature has been implemented by using the typing facility of the SIMH breakpoints.

6.2 Instruction breakpoints (8080/Z80/8086)

One can also set a breakpoint once a certain instruction is executed. To set an instruction breakpoint enter

```
sim> break -I <first byte of instruction>
```

Execution will stop whenever an instruction is executed which starts with <first byte of instruction>.

6.3 Breakpoints and instruction history (8080/Z80 only)

One can use breakpoints with the CPU instruction history. For example, suppose one wanted to determine what lead up to memory address 05C00 being accessed:

```
sim> break -m 5c00
sim> set cpu history=32
sim> g ff00
```

Memory access breakpoint [05c00h], PC: 0FF29 (MOV M,A)

```
sim> show cpu history=10
```

```
CPU: C0Z1M0E1I0 A=16 B=0000 D=0000 H=0000 S=0000 P=FF0D OUT 0FEh
CPU: C0Z1M0E1I0 A=12 B=0000 D=0000 H=0000 S=0000 P=FF0F MVI A,12h
CPU: C0Z1M0E1I0 A=12 B=0000 D=0000 H=0000 S=0000 P=FF11 OUT 0FEh
CPU: C0Z1M0E1I0 A=00 B=0000 D=0000 H=0000 S=0000 P=FF13 IN 0FEh
CPU: C0Z1M0E1I0 A=00 B=0000 D=0000 H=0000 S=0000 P=FF15 ORA A
CPU: C0Z1M0E1I0 A=00 B=0000 D=0000 H=0000 S=0000 P=FF16 JZ 0FF20h
CPU: C0Z1M0E1I0 A=00 B=0000 D=0000 H=5C00 S=0000 P=FF20 LXI H,5C00h
CPU: C0Z1M0E1I0 A=00 B=0000 D=FF33 H=5C00 S=0000 P=FF23 LXI D,0FF33h
CPU: C0Z1M0E1I0 A=00 B=0088 D=FF33 H=5C00 S=0000 P=FF26 MVI C,88h
CPU: C0Z1M0E1I0 A=31 B=0088 D=FF33 H=5C00 S=0000 P=FF28 LDAX D
```

7 Brief summary of all major changes to the original Altair simulator

- Full support for Z80. CP/M software requiring a Z80 CPU now runs properly. DDTZ and PROLOGZ are included for demonstration purposes.
- Added banked memory support.
- PC queue implemented.
- Full assembler and dis-assembler support for Z80 and 8080 mnemonics. Depending on the current setting of the CPU, the appropriate mnemonics are used.
- The BOOT ROM was changed to fully load the software from disk. The original code basically loaded a copy of itself from the disk and executed it.
- ROM and memory size settings are now fully honored. This means that you cannot write into the ROM or outside the defined RAM (e.g. when the RAM size was truncated with the SET CPU commands). This feature allows programs which check for the size of available RAM to run properly (e.g. 4k Basic). In addition one can enable and disable the ROM which is useful in special cases (e.g. when testing a new version of the ROM).
- The console can also be used via Telnet. This is useful when a terminal is needed which supports cursor control such as a VT100. PROLOGZ for example has a built-in screen editor which works under Telnet.
- Simplified file exchange for CP/M. Using the READ resp. R program under CP/M one can easily import files into CP/M from the regular file system. Note that PIP does not work properly on non-text files on PTR.
- The WRITE resp. W program can be used to transfer files from the CP/M environment to the regular environment (binary or ASCII transfer).
- The last character read from PTR is always Control-Z (the EOF character for CP/M). This makes sure that PIP (Peripheral Interchange Program on CP/M) will terminate properly.
- Fixed a bug in the BIOS warm boot routine which caused CP/M to crash.
- Modified the BIOS for CP/M to support 8 disks.
- Added CP/M 3 banked version as sample software
- Changed from octal to hex
- Made the DSK and SIO device more robust (previously malicious code could crash the simulator)
- Added memory access break points
- Added periodic timer interrupts (useful for MP/M)
- Added additional consoles (useful for MP/M)
- Added MP/M II banked version as sample software
- Added networking support for CP/NET and CPNOS

8 Appendix: Python script for converting MBL files to plain binary files

```
#!/usr/bin/python
# -*- coding: UTF-8 -*-
```

```

# formatted for tab-stops 4
#
#   By Peter Schorn, peter.schorn@acm.org, September 2006
#
#
# Transform an MBL file to a binary file suitable for loading with SIMH
#
# Structure of MBL files is as follows:
# <byte>+ 0x00 0x00
# (checksum<byte> 0x3c count<byte> loadLow<byte> loadHigh<byte>
#  <byte> * count)+
# where the lower 8 bit of the load address are determined by loadLow
# and the upper 8 bit of the load address are determined by loadHigh
# For checksum the following rules hold:
#   For the first load record: 0
#   For the second load record: (sum of all load bytes of the first
#     load record) mod 256
#   For the third and higher load records: (sum of all load bytes of
#     the preceding load record - 1) mod 256
# A header with count = 0 or second position is unequal to 0x3c denotes
# end of file.

import sys

CHR0 = 2    # i.e. first header is prefixed by 2 chr(0)

if len(sys.argv) <> 3:
    print 'Usage %s inputmbl.bin output.bin\n' % sys.argv[0]
    sys.exit(1)

f = file(sys.argv[1], 'rb')
b = f.read()
f.close()
i = b.index(chr(0) * CHR0 + chr(0) + chr(0x3c)) + CHR0 + 2
result = [chr(0)] * len(b)

k = 0
count = ord(b[i])
while count and (ord(b[i - 1]) == 0x3c):
    l = ord(b[i + 1]) + (ord(b[i + 2]) << 8)
    checksum = 0
    for j in range(count):
        result[l + j] = b[i + 3 + j]
        checksum += ord(b[i + 3 + j])
    expectedChecksum = ord(b[i-2])
    receivedChecksum = expectedChecksum
    if k == 1:
        receivedChecksum = previousChecksum & 255
    elif k > 1:
        receivedChecksum = (previousChecksum - 1) & 255
    if receivedChecksum <> expectedChecksum:
        print 'Checksum error in record %i. Got %02X and expected %02X ' % (
            k, receivedChecksum, expectedChecksum)
    i += count + 5
    count = ord(b[i])
    k += 1
    previousChecksum = checksum

```

```

i = len(result)
while result[i - 1] == chr(0):
    i -= 1

f = file(sys.argv[2], 'wb+')
for c in result[:i]:
    f.write(c)
f.close()
print '%i load records processed and %i bytes written to %s' % (k, i,
    sys.argv[2])

```

9 Appendix: How to bring up UCSD Pascal II.0 on SIMH

Precondition: Your current working directory contains the files mentioned below and altairz80 is available. The files *.raw.gz are here: http://bitsavers.org/bits/UCSD_Pascal/ucsd_II.0/

U002A.5_Z80_SYS1.raw.gz U012.1_SYS_2.raw.gz ucsd ucsd.dsk

Step 1: Get U002A.5_Z80_SYS1.raw.gz and U012.1_SYS_2.raw.gz from the distribution and gunzip "gunzip *gz".

Step 2: Patch H command with ZAP (H command will otherwise indefinitely loop as patched command is a jump to itself). Execute altairz80 with "altairz80 ucsd", type ^E and "G 0" at the "sim>" command prompt. This brings you back to CP/M. At the "E>" type "ZAP" to invoke the disk editor for fixing on drive A: sector 13 on track 5 as shown below.

- Change drive to A (D command)
- Select track/Sector (S command)
- Select Track (T command) - type 5 <return>
- Select Sector (S command) - type C <return>
- Edit sector (E command)

change

```
000060  C2 96 1A 21  FF FF C3 AC  1A C3 E9 1A  D1 2A 1A 03  |B..!C,.Ci.Q*..|
```

to

```
000060  C2 96 1A 21  FF FF C3 AC  1A C3 00 00  D1 2A 1A 03  |B..!C,.Ci.....|
```

- Commit change with ^W command
- Exit ZAP with Z command
- Exit simulator (^E and bye)

before

| | Current Track | | | | Current Sector | | | | Current Block | | | | Current Drive | | | | |
|--------|---------------|----|----|----|----------------|----|----|----|---------------|----|----|----|---------------|----|----|----|-------------------|
| | 0005 | | | | 000C | | | | 000B | | | | A: | | | | |
| Offset | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F | -----ASCII----- |
| 000000 | 09 | 29 | 29 | EB | 01 | 36 | 00 | 2A | 94 | 02 | 19 | 09 | C9 | E1 | 22 | 90 | .)k.6.*...Ia". |
| 000010 | 02 | E1 | 22 | 92 | 02 | D1 | EB | 22 | 94 | 02 | EB | 2A | 90 | 02 | 06 | 08 | .a"..Qk"..k*... |
| 000020 | 1A | BE | C2 | BA | 1A | 23 | 13 | 10 | F7 | 21 | 00 | 00 | E5 | 2A | 94 | 02 | .>B:.#..w!..e*.. |
| 000030 | EB | 2A | 92 | 02 | 73 | 23 | 72 | C3 | A4 | 03 | D2 | D3 | 1A | 2A | 94 | 02 | k*..s#rC\$.RS.*.. |
| 000040 | 11 | 08 | 00 | 19 | 5E | 23 | 56 | 7B | 3D | B2 | C2 | 96 | 1A | 21 | 01 | 00 | ...^#V{=2B...!.. |
| 000050 | C3 | AC | 1A | 2A | 94 | 02 | 11 | 0A | 00 | 19 | 5E | 23 | 56 | 7B | 3D | B2 | C,*.....^#V{=2 |
| 000060 | C2 | 96 | 1A | 21 | FF | FF | C3 | AC | 1A | C3 | E9 | 1A | D1 | 2A | 1A | 03 | B..!C,.Ci.Q*.. |
| 000070 | EB | 73 | 23 | 72 | D1 | 2A | 1C | 03 | EB | 73 | 23 | 72 | C3 | B0 | 03 | 07 | ks#rQ*..ks#rC0.. |

after

| | Current Track | | | | Current Sector | | | | Current Block | | | | Current Drive | | | | |
|--------|---------------|----|----|----|----------------|----|----|----|---------------|----|----|----|---------------|----|----|----|-------------------|
| | 0005 | | | | 000C | | | | 000B | | | | A: | | | | |
| Offset | 0 | 1 | 2 | 3 | 4 | 5 | 6 | 7 | 8 | 9 | A | B | C | D | E | F | -----ASCII----- |
| 000000 | 09 | 29 | 29 | EB | 01 | 36 | 00 | 2A | 94 | 02 | 19 | 09 | C9 | E1 | 22 | 90 | .)k.6.*...Ia". |
| 000010 | 02 | E1 | 22 | 92 | 02 | D1 | EB | 22 | 94 | 02 | EB | 2A | 90 | 02 | 06 | 08 | .a"..Qk"..k*... |
| 000020 | 1A | BE | C2 | BA | 1A | 23 | 13 | 10 | F7 | 21 | 00 | 00 | E5 | 2A | 94 | 02 | .>B:..#.w!..e*.. |
| 000030 | EB | 2A | 92 | 02 | 73 | 23 | 72 | C3 | A4 | 03 | D2 | D3 | 1A | 2A | 94 | 02 | k*..s#rC\$.RS.*.. |
| 000040 | 11 | 08 | 00 | 19 | 5E | 23 | 56 | 7B | 3D | B2 | C2 | 96 | 1A | 21 | 01 | 00 |^#V{=2B...!.. |
| 000050 | C3 | AC | 1A | 2A | 94 | 02 | 11 | 0A | 00 | 19 | 5E | 23 | 56 | 7B | 3D | B2 | C,..*.....^#V{=2 |
| 000060 | C2 | 96 | 1A | 21 | FF | FF | C3 | AC | 1A | C3 | 00 | 00 | D1 | 2A | 1A | 03 | B..!C,.Ci..... |
| 000070 | EB | 73 | 23 | 72 | D1 | 2A | 1C | 03 | EB | 73 | 23 | 72 | C3 | B0 | 03 | 07 | ks#rQ*..ks#rC0.. |

Step 3: Proceed to UCSD Pascal by typing "pascal" <return> at the "E>" command prompt. Type <return> until you see the menu bar:

Command: E(dit, R(un, F(ile, C(omp, L(ink, X(ecute, A(ssem, D(ebug,? [II.0]

X(ecute setup and choose Prompted mode to update parameters as follows:

Command: E(dit, R(un, F(ile, C(omp, L(ink, X(ecute, A(ssem, D(ebug,? [II.0]x

Execute what file? setup
INITIALIZING.....
.....
SETUP: C(HANGE T(EACH H(ELP Q(UIT [D1]

C

CHANGE: S(INGLE) P(ROMPTED) R(ADIX)
H(ELP) Q(UIT)

P

FIELD NAME = **BACKSPACE**
OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
10 8 8 BS ^H
N WANT TO CHANGE THIS VALUE? (Y,N,!)

FIELD NAME = **EDITOR ACCEPT KEY**
OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
0 0 0 NUL ^@
Y WANT TO CHANGE THIS VALUE? (Y,N,!)

26 NEW VALUE: 26
OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
32 26 1A SUB ^Z
N WANT TO CHANGE THIS VALUE? (Y,N,!)

FIELD NAME = **EDITOR ESCAPE KEY**
OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
33 27 1B ESC ^[
N WANT TO CHANGE THIS VALUE? (Y,N,!)

FIELD NAME = **ERASE LINE**
OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
0 0 0 NUL ^@
N WANT TO CHANGE THIS VALUE? (Y,N,!)

FIELD NAME = **ERASE SCREEN**
OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
0 0 0 NUL ^@
N WANT TO CHANGE THIS VALUE? (Y,N,!)

FIELD NAME = **ERASE TO END OF LINE**
OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
0 0 0 NUL ^@

```

Y  WANT TO CHANGE THIS VALUE? (Y,N,!)
75 NEW VALUE: 75
   OCTAL DECIMAL HEXADECIMAL ASCII
   113    75    4B      K
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
   FIELD NAME = ERASE TO END OF SCREEN
   OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
   0      0      0      NUL   ^@
Y  WANT TO CHANGE THIS VALUE? (Y,N,!)
74 NEW VALUE: 74
   OCTAL DECIMAL HEXADECIMAL ASCII
   112    74    4A      J
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
   FIELD NAME = HAS 8510A
   CURRENT VALUE IS FALSE
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
   FIELD NAME = HAS BYTE FLIPPED MACHINE
   CURRENT VALUE IS FALSE
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
   FIELD NAME = HAS CLOCK
   CURRENT VALUE IS FALSE
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
   FIELD NAME = HAS LOWER CASE
   CURRENT VALUE IS FALSE
Y  WANT TO CHANGE THIS VALUE? (Y,N,!)
T  NEW VALUE: T
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
   FIELD NAME = HAS RANDOM CURSOR ADDRESSING
   CURRENT VALUE IS FALSE
Y  WANT TO CHANGE THIS VALUE? (Y,N,!)
T  NEW VALUE: T
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
   FIELD NAME = HAS SLOW TERMINAL
   CURRENT VALUE IS FALSE
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
   FIELD NAME = HAS WORD ORIENTED MACHINE
   CURRENT VALUE IS FALSE
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
   FIELD NAME = KEY FOR BREAK
   OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
   0      0      0      NUL   ^@
Y  WANT TO CHANGE THIS VALUE? (Y,N,!)
3  NEW VALUE: 3
   OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
   3      3      3      ETX   ^C
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
   FIELD NAME = KEY FOR FLUSH
   OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
   6      6      6      ACK   ^F
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
   FIELD NAME = KEY FOR STOP
   OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
   23     19     13      DC3   ^S

```

```

N  WANT TO CHANGE THIS VALUE? (Y,N,!)
    FIELD NAME = KEY TO DELETE CHARACTER
        OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
            10      8      8      BS      ^H
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
    FIELD NAME = KEY TO DELETE LINE
        OCTAL DECIMAL HEXADECIMAL ASCII
            177     127     7F      DEL
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
    FIELD NAME = KEY TO END FILE
        OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
            3       3       3       ETX    ^C
Y  WANT TO CHANGE THIS VALUE? (Y,N,!)
26  NEW VALUE: 26
    OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
        32      26     1A      SUB    ^Z
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
    FIELD NAME = KEY TO MOVE CURSOR DOWN
        OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
            12      10      A      LF     ^J
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
    FIELD NAME = KEY TO MOVE CURSOR LEFT
        OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
            10      8       8      BS     ^H
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
    FIELD NAME = KEY TO MOVE CURSOR RIGHT
        OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
            34      28      1C      FS     ^\
Y  WANT TO CHANGE THIS VALUE? (Y,N,!)
12  NEW VALUE: 12
    OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
        14      12       C      FF     ^L
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
    FIELD NAME = KEY TO MOVE CURSOR UP
        OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
            37      31      1F      US     ^_
Y  WANT TO CHANGE THIS VALUE? (Y,N,!)
11  NEW VALUE: 11
    OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
        13      11       B      VT     ^K
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
    FIELD NAME = LEAD IN FROM KEYBOARD
        OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
            0       0       0      NUL   ^@
N  WANT TO CHANGE THIS VALUE? (Y,N,!)
    FIELD NAME = LEAD IN TO SCREEN
        OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
            0       0       0      NUL   ^@
Y  WANT TO CHANGE THIS VALUE? (Y,N,!)
27  NEW VALUE: 27
    OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
        33      27      1B      ESC   ^[
N  WANT TO CHANGE THIS VALUE? (Y,N,!)

```

```

FIELD NAME = MOVE CURSOR HOME
OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
  15   13   D   CR   ^M
Y WANT TO CHANGE THIS VALUE? (Y,N,!)
72 NEW VALUE: 72
OCTAL DECIMAL HEXADECIMAL ASCII
  110   72   48   H
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = MOVE CURSOR RIGHT
OCTAL DECIMAL HEXADECIMAL ASCII
  41   33   21   !
Y WANT TO CHANGE THIS VALUE? (Y,N,!)
68 NEW VALUE: 68
OCTAL DECIMAL HEXADECIMAL ASCII
  104   68   44   D
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = MOVE CURSOR UP
OCTAL DECIMAL HEXADECIMAL ASCII CONTROL
  0     0     0     NUL   ^@
Y WANT TO CHANGE THIS VALUE? (Y,N,!)
65 NEW VALUE: 65
OCTAL DECIMAL HEXADECIMAL ASCII
  101   65   41   A
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = NON PRINTING CHARACTER
OCTAL DECIMAL HEXADECIMAL ASCII
  77   63   3F   ?
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[DELETE CHARACTER]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[EDITOR ACCEPT KEY]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[EDITOR ESCAPE KEY]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[ERASE LINE]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[ERASE SCREEN]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[ERASE TO END OF LINE]
CURRENT VALUE IS FALSE
Y WANT TO CHANGE THIS VALUE? (Y,N,!)
T NEW VALUE: T
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[ERASE TO END OF SCREEN]
CURRENT VALUE IS FALSE
Y WANT TO CHANGE THIS VALUE? (Y,N,!)
T NEW VALUE: T
N WANT TO CHANGE THIS VALUE? (Y,N,!)

```

```

FIELD NAME = PREFIXED[KEY FOR BREAK]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[KEY FOR FLUSH]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[KEY FOR STOP]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[KEY TO DELETE CHARACTER]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[KEY TO DELETE LINE]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[KEY TO END FILE]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[KEY TO MOVE CURSOR DOWN]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[KEY TO MOVE CURSOR LEFT]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[KEY TO MOVE CURSOR RIGHT]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[KEY TO MOVE CURSOR UP]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[MOVE CURSOR HOME]
CURRENT VALUE IS FALSE
Y WANT TO CHANGE THIS VALUE? (Y,N,!)
T NEW VALUE: T
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[MOVE CURSOR RIGHT]
CURRENT VALUE IS FALSE
Y WANT TO CHANGE THIS VALUE? (Y,N,!)
T NEW VALUE: T
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[MOVE CURSOR UP]
CURRENT VALUE IS FALSE
Y WANT TO CHANGE THIS VALUE? (Y,N,!)
T NEW VALUE: T
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = PREFIXED[NON PRINTING CHARACTER]
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = SCREEN HEIGHT
OCTAL DECIMAL HEXADECIMAL
    30    24    18
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = SCREEN WIDTH

```

```

OCTAL DECIMAL HEXADECIMAL
  120    80    50
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = STUDENT
CURRENT VALUE IS FALSE
N WANT TO CHANGE THIS VALUE? (Y,N,!)
FIELD NAME = VERTICAL MOVE DELAY
OCTAL DECIMAL HEXADECIMAL
  5      5      5
Y WANT TO CHANGE THIS VALUE? (Y,N,!)
O NEW VALUE: 0
OCTAL DECIMAL HEXADECIMAL
  0      0      0
N WANT TO CHANGE THIS VALUE? (Y,N,!)
CHANGE: S(INGLE) P(ROMPTED) R(ADIX)
Q H(ELP) Q(UIT)
Q SETUP: C(HANGE T(EACH H(ELP Q(UIT [D1]
D QUIT: D(ISK) OR M(EMORY) UPDATE,
R(ETURN) H(ELP) E(XIT)
M QUIT: D(ISK) OR M(EMORY) UPDATE,
R(ETURN) H(ELP) E(XIT)
E QUIT: D(ISK) OR M(EMORY) UPDATE,
R(ETURN) H(ELP) E(XIT)

```

Step 4: Rename NEW.MISCINFO to SYSTEM.MISCINFO

```

Command: E(dit, R(un, F(ile, C(omp, L(ink, X(ecute, A(sssem, D(ebug,? [II.0]
F
Filer: G(et, S(ave, W(hat, N(ew, L(dir, R(em, C(hng, T(rans, D(ate, Q(uit [B]
L
Dir listing of what vol ? *
Filer: G(et, S(ave, W(hat, N(ew, L(dir, R(em, C(hng, T(rans, D(ate, Q(uit [B]L
U002A.5:
SYSTEM.STARTUP      5 28-Feb-79
SYSTEM.MICRO        16 9-Feb-79
Z80T.MICRO          19 9-Feb-79
SYSTEM.FILER        28 10-Apr-79
SYSTEM.PASCAL       33 7-Mar-79
SYSTEM.EDITOR       45 10-Feb-79
SYSTEM.LINKER       22 10-Feb-79
SYSTEM.COMPILER     68 8-Feb-79
SYSTEM.LIBRARY      8 17-Apr-79
SYSTEM.SYNTAX       14 2-May-79
SAMPLEGOTO.TEXT    4 17-Nov-78
SETUP.CODE          25 14-May-79
READ.ME.TEXT        4 17-Apr-79
BINDER.CODE         6 3-May-79
NEW.MISCINFO        1 10-Feb-79
15/15 files<listed/in-dir>, 308 blocks used, 186 unused, 186 in largest
Filer: G(et, S(ave, W(hat, N(ew, L(dir, R(em, C(hng, T(rans, D(ate, Q(uit [B]
C
Change what file ? NEW.MISCINFO
Change to what ? SYSTEM.MISCINFO

```

Step 5: Delete SYSTEM.STARTUP (R command in Filer)

Step 6: Set date with D command in Filer

Step 7: Create new goto file for VT100 (VT100GOTO.TEXT)

```
(* $U-*)  
PROGRAM DUMMY;  
  
(* Direct cursor addressing for VT100 terminal *)  
(* '[' after escape is done by BIOS - trick from Udo Munk *)  
PROCEDURE FGOTOXY(X,Y:INTEGER);  
BEGIN  
    IF X<0 THEN X:=0;  
    IF X>79 THEN X:=79;  
    IF Y<0 THEN Y:=0;  
    IF Y>23 THEN Y:=23;  
    WRITE (CHR(27),Y+1,';',X+1,'H')  
END;  
BEGIN  
END.
```

Take SAMPLEGOTO.TEXT as basis and modify using the editor. You can delete a complete line by moving the cursor to the line (^J for down, ^K for up) and then do D and <return> and ^Z.

Step 8: Compile result and save codefile (using Filer Save command).

Step 9: Update SYSTEM.PASCAL by X)cuting BINDER. When prompted for the file with the procedure type in VT100GOTO. The change takes effect after restart: Type H at top level and "pascal" at E> prompt.

10 Vector Graphic, Inc. Simulation

Howard M. Harte, hharte@hartetec.com

10.1 Overview

Vector Graphic is an early microcomputer from the mid 1970's, based on the [S-100](#) bus using the [Z80](#) microprocessor. There were several Vector Graphic models produced. Although primarily used with the [CP/M](#) operating system, it ran several others including [OASIS](#), Micropolis Disk Operating System (MDOS), and Micropolis Z80 Operating System (MZOS).

Early Vector Graphic models used the Micropolis floppy disk controller and Micropolis floppy disk drives. Later models were designed with the integrated Floppy Drive/Hard Drive controller and used Tandon floppy drives. Almost all used unusual 100 track per inch 5.25" floppy drives and 16 sector 5.25" hard sector media. Some models included 8" floppy drives and hard disk drives.

Vector Graphic computers had many innovations such as the Flashwriter integrated video and keyboard controller. Vector Graphic is commonly known for their MEMORITE word processing application. When combined with the Flashwriter, the Vector Graphic MEMORITE software gave low cost word processing capability which had previously only been available with dedicated word processors.

Vector Graphic has a small but active user community. The following are links to resources and information about the Vector Graphic computer systems:

History and Background

http://en.wikipedia.org/wiki/Vector_Graphic

<http://old-computers.com/museum/company.asp?st=1&l=V>

<http://www.classiccmp.org/dunfield/s100/index.htm#v1p>

<http://www.vintage-computer.com/vector1plus.shtml>

http://retrotechnology.com/herbs_stuff/d_vector.html

<http://www.vectorgraphics.org.uk/>

Mailing List

<http://h-net.msu.edu/cgi-bin/wa?A0=VECTOR-GRAPHIC>

Documentation

<http://www.hartetechnologies.com/manuals/Vector%20Graphics/>

<http://maben.homeip.net/static/S100/vector/index.html>

Documentation / Disk Images

<http://vector-archive.org>

The Vector Graphic simulation was realized by making several architectural modifications to support additional disk controllers and the Flashwriter2 video card. The architectural modifications include the ability to install and uninstall devices in the simulator's memory and I/O map at runtime, and pave the way for further extension of SIMH/AltairZ80 to support other hardware with a minimum of integration effort.

These additional devices specific to the Vector Graphic systems include:

MDSK – Micropolis FD Controller Board, memory mapped to 0xF800-0xFBFF

VFDHD – Vector HD-FD Controller Board, I/O Mapped to 0xC0-0xC3

FWII – Flashwriter 2 Video Card, memory mapped to 0xF000-0xF800

These devices can be enabled/disabled (installed/uninstalled) from the memory map with:

```
sim> set <device> ena - to enable the device.  
sim> set <device> dis - to disable the device.
```

If there is an I/O or memory map conflict when enabling a device, the conflicting device must first be disabled.

In addition to the new devices added to SIMH/AltairZ80, additional ROM images are provided for the Vector 4.0C Monitor and the Vector 4.3 Monitor. The 4.0C Monitor uses the simulated serial port for I/O, and the 4.3 Monitor uses the Flashwriter2 video card for output and a simulated parallel keyboard for input. One of these monitors should be loaded at address 0xE000, depending on the simulated system configuration.

Generally, when using the HD-FD disk controller, you will need to use Monitor 4.3, since it supports booting from this controller. When using the Micropolis FD Controller board, you should use the 4.0C Monitor.

The simulator can be configured for a 48K Vector MZ or a 56K Vector MZ. Some boot disk images require a 48K configuration, and some require a 56K configuration. In the 48K configuration on a real Vector MZ system, an older version of the monitor ROM was at address 0xC000. Since the image for this ROM has not been obtained, a small “helper” ROM is loaded at address 0xC000, in addition to the 4.0C Monitor at 0xE000. The “helper” ROM redirects calls to perform terminal I/O to the corresponding entry points in the 4.0C monitor.

There are several configuration files that configure SIMH to simulate various Vector Graphic systems. These configuration files are the definitive reference for proper simulator configuration, and should be preferred over the following descriptions if there is any discrepancy. These configuration files are:

```
vgmz48k      Vector 48K MZ with Micropolis FD Controller  
vgmz56k      Vector 56K MZ with Micropolis FD Controller  
vgfdhd      Vector 56K System with HD-FD Disk Controller
```

Here are some sample configurations for 48K, 56K, and HD-FD Systems:

10.2 48K Vector MZ

```
sim> load MON40C.BIN e000 - load Vector 4.0C Monitor  
sim> load MONC000.BIN c000 - load “Helper” ROM at 0xC000  
sim> set mdsk membase=D800 - set Micropolis disk controller base address  
sim> set mdsk enabled      - enable Micropolis disk controller  
sim> attach mfdc0 VG02.VGI - attach disk to MDSK0 drive
```

When booting the 48K configuration, type:

```
sim> g e000
```

and at the `Mon>` prompt, you can boot from the disk controller by doing `G D800`.

10.3 56K Vector MZ

```
sim> load MON40C.BIN e000      - load Vector 4.0C Monitor
sim> set mdsk enabled         - enable Micropolis disk controller
sim> attach mfdc0 VG00.VGI    - attach disk to MDSK0 drive
```

When booting the 56K configuration, type:

```
sim> g e000
```

and at the `Mon>` prompt, you can boot from the disk controller by using the **B** (boot) command.

10.4 56K Vector with HD-FD Controller

```
sim> set vfdhd enabled       - enable HD-FD controller
sim> load MON43B.BIN e000    - load Vector 4.3 Monitor
sim> att fwii0 f000         - enable the Flashwriter2 at F000.
sim> set telnet 23          - set up telnet port for Flashwriter2
sim> attach vfdhd1 VGBOOT.VGI - attach disk to VFDHD1 drive
```

When booting the 56K HD-FD configuration, type:

```
sim> g e000
```

You will then need to start a Telnet session to the simulator to use the simulated Flashwriter2. From a console window, do `telnet localhost 23`, or use your favorite telnet client, such as “Putty” under Windows. In the Telnet window, the 4.3 Monitor should sign on and at the `Mon>` prompt, you can boot from the disk controller by using the **B** (boot) command.

10.5 Notes on Simulated Hardware

The Vector HD-FD Controller supports four drives, one of which may be a Winchester (hard disk) drive. For the included VGBOOT.VGI disk image, CP/M is configured such that the VFDHD0 is drive "B" and VFDHD1 is drive "A." VFDHD2 is drive "C" and VFDHD3 is drive "D." The simulation assumes that whatever image is attached to VFDHD0 is a "Hard disk" image, so drive "B" using the VGBOOT.VGI disk image is not supported.

10.6 Notes on the Vector Graphic Disk Image (VGI) File Format

The Vector Graphic Disk Image (VGI) File Format uses a 275-byte sector format. This sector includes 256 bytes of User Data, and various other fields (metadata) used by controller hardware and the operating system running on the simulator.

The 275-byte sector format is as follows:

| SYNC | TRACK | SECTOR | UNUSED | USER DATA | CHKSUM | ECC | ECC_VALID |
|------|-------|--------|--------|-----------|--------|-----|-----------|
| 1 | 1 | 1 | 10 | 256 | 1 | 4 | 1 |

| | |
|-----------|---|
| SYNC | One byte, always 0xFF. |
| TRACK | Track number that this sector belongs to. |
| SECTOR | Sector number |
| UNUSED | Used by the operating system when running Micropolis DOS (MDOS) to store the load address and record length for the sector. This field is not used by CP/M. |
| USER DATA | 256-bytes of user data |
| CHECKSUM | An operating system dependent checksum. |
| ECC | Four bytes of ECC code, generated and checked by the HD-FD Controller, but not used by the Micropolis FD Controller |
| ECC_VALID | One byte that contains 0xAA if the ECC field is valid. Disks written by the HD-FD controller typically have this field set to 0xAA to indicate that the ECC field should contain valid data. For disk images created by the Micropolis FD controller, this field is 0x00, since ECC is not supported. For disk images that were generated using the CPT program, this field will be 0x00 because the ECC bytes were not recoverable from the original disk. For disk images originally written with the HD-FD Controller, and imaged with Catweasel/Vector Graphic (CWVG) this field will be set to whatever it was set to on the original disk. This should be 0xAA. |

11 IMSAI 8080 Simulation

IMSAI FIF Disk Controller support was added by Ernie Price.

11.1 Overview

The IMSAI FIF Disk Controller consists of an IFM (Interface Master Board) and a FIB (Floppy Disk Interface board) which interface the disk to the computer. The combination of FIB and IFM boards create an intelligent controller including DMA transfer, which permits the computer to perform other tasks during disk operations.

The FIF simulation can control up to eight disk drives. Commands include Read Clock and Data Bits, Write Sector, Read Sector, Verify Sector, Format Track, Write Deleted Data Sector Mark, Write Protect, Write Enable and Restore Drive. Logical and physical track addresses may be different. Cyclic redundancy checks are performed automatically. When an error is detected in reading or writing, the logic automatically retries up to 10 times.

Using the IMSAI FIF Controller, it is possible to run IMDOS 2.05 on the simulator.

Additional devices include:

FIF – IMSAI FIF Disk Controller, I/O Mapped to 0xFD

Since the IMSAI FIF and AltairZ80 HDSK devices both use I/O port 0xFD, the HDSK must be disabled before enabling the FIF:

```
sim> set hdsk dis - disable the AltairZ80 HDSK device.
sim> set fif ena - enable the IMSAI FIF device.
```

There is a configuration file that configures SIMH to simulate an IMSAI 8080 with FIF Disk Controller. This configuration file is the definitive reference for proper simulator configuration, and should be preferred over the following description if there is any discrepancy. This configuration file is:

```
imdos          IMSAI 8080 with FIF Disk Controller
```

11.2 IMSAI 8080 with FIF Disk Controller

```
sim> set hdsk dis          - disable AltairZ80 HDSK Controller
sim> set fif ena          - enable IMSAI FIF Controller
sim> load IMSAI.BIN d800   - load IMSAI Monitor at 0xD800
sim> attach fif0 IMDOS_A.DSK - attach disk to FIF0 drive
```

When booting the IMSAI 8080 with FIF Disk Controller, type:

```
sim> g d800
```

This will start the IMSAI Monitor, which will automatically boot from FIF0 if a valid boot disk image is attached.

12 North Star MDS-A and MDS-AD FDC Simulation

North Star MDS-A (single density FDC) support was added by Mike Douglas, deramp5113@yahoo.com.

North Star MDS-AD (double density FDC) support was added by Howard M. Harte, hharte@hartetec.com.

12.1 Overview

The single density MDS-A disk controller was the first disk controller made by North Star. This controller supports 48 TPI 5.25" disks with 35 tracks and 10 hard sectors per track. Sectors are 256 bytes in length for a total storage capacity of 89,600 bytes.

Later, North Star introduced the double sided, double density, MDS-AD disk controller. This controller also uses 48 TPI 5.25" media with 35 tracks and 10 hard-sectors per track, but with 512 bytes per sector, disk capacity increased to 179,200 bytes on a single sided drive, or 358,400 bytes on a double sided drive.

The first computer offered by North Star, the Horizon, used the double density controller. However, both the single density and double density controllers were a very popular choice in Altair, IMSAI, Sol-20, and numerous other early micro computers.

12.2 MDS-A Single Density Disk Controller

The single density controller device is **MDSA**. The North Star controller is a memory mapped device in the range 0xE800-0xEBFF. The boot PROM is at 0xE900 on the single density controller. North Star documentation refers to drives as 1-3, however, the drive numbers are 0-2 in the simulation.

Following are the commands to mount and boot CP/M for the North Star Horizon computer.

```
sim> set mdsa enabled           - enable MDS-A Controller
sim> attach mdsa0 CPM22b14-48K-SDC-HORIZON.NSI - attach CP/M boot disk
sim> boot mdsa0 (or go e900)    - boot the disk
```

The referenced disk image can be found in the "cpm" folder at the link below. North Star DOS disk images can be found in the "nsdos" folder.

https://deramp.com/downloads/north_star/horizon/single_density_controller/disk_images/

Disk images for the North Star single density controller are available for a variety of different computers. Drill down the folder tree of the computer of interest at <https://deramp.com/downloads/>.

12.3 MDS-AD Double Density Disk Controller

The double density controller device is **MDSAD**. The North Star controller is a memory mapped device in the range 0xE800-0xEBFF. The boot PROM is at 0xE800 on the double density controller. North Star documentation refers to drives as 1-4, however, the drive numbers are 0-3 in the simulation.

Following are the commands to mount and boot CP/M for the North Star Horizon computer.

```
sim> set mdsad enable           - enable North Star MDS-AD Controller
sim> attach mdsad0 D01B01.NSI   - attach CP/M boot disk to MDSAD0 drive
sim> boot mdsad0 (or go e800) - boot the disk
```

There is a configuration file that configures SIMH to simulate a North Star Horizon System with an MDS-AD Disk Controller. This configuration file is the definitive reference for proper simulator configuration, and should be preferred over the preceding description if there is any discrepancy. This configuration file is:

nshrz North Star Horizon with MDS-AD Disk Controller

Additional Horizon disk images can be found in the “cpm” folder at the link below. Additional North Star DOS disk images can be found in the “nsdos” folder.

https://deramp.com/downloads/north_star/horizon/double_density_controller/disk_images/

Disk images for the North Star double density controller are available for a variety of different computers. Drill down the folder tree of the computer of interest at <https://deramp.com/downloads/>.

13 Compupro 8-16 Simulation

Compupro Controller support was added by Howard M. Harte, hharte@hartetec.com. The 8086 simulation was added by Peter Schorn.

13.1 Overview

The Compupro 8-16 was a fairly advanced IEEE-696 bus based system that included a dual CPU card containing Intel 8085 and 8088 processors. This processor card was capable of switching between CPUs at runtime, and this allowed the user to run CP/M-80 as well as CP/M-86. In the latest version of CP/M-80 released by Viasyn (who had acquired Compupro by that time) uses the 8085 CPU for running CP/M, but offloads some of the memory operations to the 8088 CPU because of its ability to operate faster, and more easily address memory above 64K.

Additional devices include:

DISK1A – Compupro DISK1A High Performance Floppy Disk Controller.

DISK2 – Compupro DISK2 Hard Disk Controller.

DISK3 – Viasyn DISK3 Hard Disk Controller for ST-506 Drives.

SELCHAN – Compupro Selector Channel DMA Controller.

MDRIVEH – Compupro MDRIVE/H RAM Disk (up to 4MB.)

SS1 – Compupro System Support 1 (experimental and incomplete simulation.)

There are configuration files that configure SIMH to simulate a Compupro 8-16, with various attached controllers to run CP/M-80 and CP/M-86. These configuration files are:

| | |
|----------------------|--|
| <code>ccpm22</code> | Compupro 8-16 CP/M-80 2.2 |
| <code>ccpm86</code> | Compupro 8-16 CP/M-86 |
| <code>ccpm22q</code> | Compupro 8-16 CP/M-80 2.2Q (latest Viasyn version) |

13.2 DISK1A High Performance Floppy Disk Controller

The DISK1A High Performance Floppy Disk Controller is based on the Intel i8272 Floppy Disk Controller chip, which is the same as an NEC765 floppy controller. The implementation of the DISK1A uses a generic i8272 controller core with a DISK1A-specific wrapper to implement the Compupro DISK1A-specific features.

The i8272 controller core simulation utilizes the ImageDisk (IMD) file format for accessing simulated floppy disks.

The DISK1A simulation also includes the Compupro bootstrap ROM, which contains bootloaders for 8085, 8088, and 68000 CPUs.

Tony Nicholson provided several enhancements to the DISK1A controller simulation, including variable sector size support, as well as extended addressing support for DMA data transfer.

13.2.1 DISK1A Controller Parameters

The DISK1A controller supports several parameters which can be configured by the simulator:

ROM – Enable bootstrap ROM at 0000-01FFh.

NOROM – Disable bootstrap ROM.

DEBUG – enable debug tracing, useful for debugging software. One or more debug levels may be selected at any given time. Several debug tracing levels are provided:

- ERROR – Error messages, these are bugs in the simulation or in the way a program running on the simulator accesses the controller. This message level is on by default.
- SEEK – Seek messages, related to head positioning.
- CMD – Disk controller commands.
- RDDATA – Read Data messaging
- WRDATA – Write Data messaging
- STATUS – Status register reading
- VERBOSE – Extra verbosity for debugging.

NODEBUG – turn off one or more debug message levels.

The DISK1A supports four drives, labeled DISK1A0 through DISK1A3. If a drive is attached to a non-existent image file, the image file will be created, and the user will be asked for a comment description of the disk. SIMH adds its own IMD header to the comment field, along with information about the version of the controller core (in this case i8272) as well as the SIM_IMD module, to help facilitate debugging. The SIM_IMD module will automatically format the new disk image in IBM 3740 Single-Sided, Single-Density format. If the user wishes to use the disk in another format, then it should be reformatted using the CompuPro format program on either CP/M-80 or CP/M-86.

13.2.2 DISK1A Controller Limitations

The DISK1A controller and the underlying i8272 controller core only support DMA-mode operation at present. There is no support for polled-mode I/O access for reading/writing data. While the DISK1A simulation is believed to be very accurate in normal operation, the error handling and bad data reporting from the SIM_IMD module are not well implemented/tested. For example, if a disk image contains a CRC error on one of the sectors, this may not be propagated up to the DISK1A status registers. This should not be an issue for disks created with SIMH, because there is no such thing as a CRC error in this case. But, for images that were read from a real floppy using IMD, a sector containing bad data might be reported as good by the simulation.

13.3 DISK2 Compupro Hard Disk Controller

The DISK2 Hard Disk Controller provides 20MB of fixed-disk storage, and supports four hard disk drives. Just like a real DISK2 controller, it needs to be used in conjunction with the Compupro Selector Channel DMA controller.

13.3.1 DISK2 Controller Parameters

The DISK2 controller supports several parameters which can be configured by the simulator:

DEBUG – enable debug tracing, useful for debugging software. One or more debug levels may be selected at any given time. Several debug tracing levels are provided:

- ERROR – Error messages, these are bugs in the simulation or in the way a program running on the simulator accesses the controller. This message level is on by default.
- SEEK – Seek messages, related to head positioning.
- CMD – Disk controller commands.
- RDDATA – Read Data messaging
- WRDATA – Write Data messaging

- STATUS – Status register reading
- VERBOSE – Extra verbosity for debugging.

NODEBUG – turn off one or more debug message levels.

13.3.2 DISK2 Controller Configuration Registers

The DISK2 controller has several configuration registers that can be examined and deposited by the simulator. The defaults are configured for a standard 20MB hard disk. These registers are:

NTRACKS – Number of tracks on the simulated hard disks.

NHEADS – Number of heads on the simulated hard disks.

NSECTORS – Number of sectors on the simulated hard disks.

SECTSIZE – Sector size on the simulated hard disks.

The DISK2 supports four drives, labeled DISK20 through DISK23. If a drive is attached to a non-existent image file, the image file will be created. A newly created disk image should be formatted with the CompuPro DISK2.COM command.

13.4 SELCHAN Compupro Selector Channel Controller

The Compupro Selector Channel DMA controller provides DMA support for the Compupro DISK2 Hard Disk Controller.

13.4.1 DISK2 Controller Parameters

The DISK2 controller supports several parameters which can be configured by the simulator:

DEBUG – enable debug tracing, useful for debugging software. One or more debug levels may be selected at any given time. Several debug tracing levels are provided:

- ERROR – Error messages, these are bugs in the simulation or in the way a program running on the simulator accesses the controller. This message level is on by default.
- DMA – DMA Transfer Messages.
- VERBOSE – Extra verbosity for debugging.

NODEBUG – turn off one or more debug message levels.

Tony Nicholson added extended addressing DMA support to the SELCHAN module.

13.5 DISK3 Viasyn ST-506 Hard Disk Controller

The DISK3 Hard Disk Controller is an advanced DMA-based hard disk controller that uses linked-list descriptors to send commands and transfer data between the host CPU and the disk controller.

13.5.1 DISK3 Controller Parameters

The DISK3 controller supports several parameters which can be configured by the simulator:

DEBUG – enable debug tracing, useful for debugging software. One or more debug levels may be selected at any given time. Several debug tracing levels are provided:

- ERROR – Error messages, these are bugs in the simulation or in the way a program running on the simulator accesses the controller. This message level is on by default.
- SEEK – Seek messages, related to head positioning.

- CMD – Disk controller commands.
- RDDATA – Read Data messaging
- WRDATA – Write Data messaging
- STATUS – Status register reading
- VERBOSE – Extra verbosity for debugging.

NODEBUG – turn off one or more debug message levels.

13.5.2 DISK3 Controller Configuration Registers

The DISK3 controller has several configuration registers that can be examined and deposited by the simulator. The defaults are configured for a standard 20MB hard disk. These registers are:

NTRACKS – Number of tracks on the simulated hard disks.

NHEADS – Number of heads on the simulated hard disks.

NSECTORS – Number of sectors on the simulated hard disks.

SECTSIZE – Sector size on the simulated hard disks.

The DISK3 supports four drives, labeled DISK30 through DISK33. If a drive is attached to a non-existent image file, the image file will be created. A newly created disk image should be formatted with the CompuPro DISK3.COM command.

13.5.3 DISK3 Controller Limitations

The DISK3 controller has been tested with the Compupro DISK3.COM diagnostic utility, but has not been tested with CP/M.

14 Cromemco 4/16/64FDC and CCS-2422 FDC Simulation

Cromemco 4/16/64FDC (CROMFDC) Floppy Controller support was added by Howard M. Harte, hharte@hartetec.com.

14.1 Overview

The Cromemco 4/16/64FDC disk controllers are a family of floppy disk controllers for Cromemco systems. The controller is based on the Western Digital WD179x series of floppy controller chips. The implementation of the DISK1A uses a generic WD179x controller core with a Cromemco-specific wrapper to implement the Cromemco-specific features.

The WD179x controller core simulation utilizes the ImageDisk (IMD) file format for accessing simulated floppy disks.

The Cromemco simulation also includes the Cromemco RDOS 2.52 and RDOS 3.12 boot ROMs.

Additional devices include:

CROMFDC – Cromemco 4/16/64FDC Floppy Disk Controller.

14.1.1 CROMFDC Controller Parameters

The CROMFDC controller supports several parameters which can be configured by the simulator:

ROM – Enable RDOS ROM at C000-DFFFh.

NOROM – Disable RDOS ROM.

DEBUG – enable debug tracing, useful for debugging software. One or more debug levels may be selected at any given time. Several debug tracing levels are provided:

- ERROR – Error messages, these are bugs in the simulation or in the way a program running on the simulator accesses the controller. This message level is on by default.
- SEEK – Seek messages, related to head positioning.
- CMD – Disk controller commands.
- RDDATA – Read Data messaging
- WRDATA – Write Data messaging
- STATUS – Status register reading
- VERBOSE – Extra verbosity for debugging.
- DRIVE – Messaging specific to drive, i.e.: Motor on/off, side selection.
- IRQ – Interrupt debugging

NODEBUG – turn off one or more debug message levels.

14.1.2 CROMFDC Controller Configuration Registers

The CROMFDC controller has several configuration registers that can be examined and deposited by the simulator. The defaults are configured for a standard 20MB hard disk. These registers are:

DIPSW – 5-position DIP switch on 64FDC card.

BOOTSTRAP – 0 for RDOS 2.52, 1 for RDOS 3.12.

FDCTYPE – CROMFDC Type: Set to 4, 16, 64 for Cromemco FDC, or 50 for CCS-2422 FDC.

BOOT – BOOT jumper setting, default is 1 (auto-boot.)

INHINIT – Inhibit Init (Format) switch, default is 0 (not inhibited.)

The CROMFDC supports four drives, labeled CROMFDC0 through CROMFDC3. If a drive is attached to a non-existent image file, the image file will be created, and the user will be asked for a comment description of the disk. SIMH adds its own IMD header to the comment field, along with information about the version of the controller core (in this case WD179x) as well as the SIM_IMD module, to help facilitate debugging. The SIM_IMD module will automatically format the new disk image in IBM 3740 Single-Sided, Single-Density format. If the user wishes to use the disk in another format, then it should be reformatted using the Cromemco INIT.COM program under Cromemco DOS (CDOS), or using the INITLARG.COM program under 86-DOS.

14.1.3 CROMFDC Controller Limitations

The CROMFDC controller and the underlying WD179x controller core only support polled I/O mode operation at present. There is no support for DMA access for reading/writing data. The CROMFDC interrupt support is not fully implemented/tested; however, none of the operating systems that use the CROMFDC controller (CDOS, CP/M 2.2, 86-DOS) seem to use this mode. Z80 Cromix does not boot in simulation, but probably not due to the lack of disk controller interrupts.

16 Tarbell MDL-1011/2022 Floppy Disk Interface Simulation

Tarbell Electronics MDL-1011/2022 Floppy Disk Interface support was added by Patrick A. Linstruth, patrick@deltecent.com.

16.1 Overview

The Tarbell MDL-1011 floppy disk interface is a single-sided, single-density disk controller supporting 8" media with 77 tracks, 26 sectors per track, with 128 byte sectors.

The Tarbell MDL-2022 floppy disk interface is a double-sided, double-density disk controller supporting 8" SSSD, SSDD, DSSD, and DSDD media with 77/154 tracks and 26/51 sectors per track, with 128 byte sectors.

Both controller models include a 32-byte PROM bootstrap loader located at 0000H that is automatically enabled when the simulator is reset and switches itself out after the bootstrap has run.

Using the Tarbell MDL-1011/2022 floppy disk interfaces, it is possible to run CP/M and other operating systems that are designed for these interfaces on the simulator.

16.1.1 TARBELL Controller Parameters

The TARBELL controller supports several parameters which can be configured by the simulator:

MODEL – Select TARBELL controller model:

- SD – MDL-1011 single density controller (default).
- DD – MDL-2022 double density controller.

WRTPROT – Enable write protect (emulates switch 6 on).

WRTENB – Enable writing to disks (emulates switch 6 off).

PROM – Enable boot PROM at 0000-001Fh (emulates switch 7 on).

NOPROM – Disable boot PROM (emulated switch 7 off).

DEBUG – Enable debug tracing, useful for debugging software. One or more debug levels may be selected at any given time. Several debug tracing levels are provided:

- ERROR – Error messages, these are bugs in the simulation or in the way a program running on the simulator accesses the controller. This message level is on by default.
- SEEK – Seek messages, related to head positioning.
- CMD – Disk controller commands.
- RDDATA – Read Data messaging
- WRDATA – Write Data messaging
- STATUS – Status register reading
- VERBOSE – Extra verbosity for debugging.

NODEBUG – Turn off one or more debug message levels.

The TARBELL controller supports four drives, labeled TARBELL0 through TARBELL3. If a drive is attached to a non-existent disk file, the disk file will be created.

16.1.2 TARBELL Example Usage

Download CPM22-48K-SSSD.DSK via

[https://deramp.com/downloads/altair/software/tarbell_floppy_controllers/single_density_controller/CPM%202.2%20\(1982\)/CPM22-48K-SSSD.DSK](https://deramp.com/downloads/altair/software/tarbell_floppy_controllers/single_density_controller/CPM%202.2%20(1982)/CPM22-48K-SSSD.DSK) for the Tarbell MDL-1011 and then

```
sim> set cpu 48k
sim> set cpu 8080
sim> set cpu noaltairrom
sim> set sio ansi
sim> set sio sleep
sim> set tarbell enable           - enable Tarbell Controller
sim> set tarbell model=sd       - single density controller
sim> set tarbell debug=ERROR    - show debug ERROR messages
sim> attach tarbell0 CPM22-48K-SSSD.DSK - attach CP/M boot disk to
                                TARBELL0 drive
sim> boot tarbell0              - boot CPM22.DSK (or "g 0")it
```

CP/M disk images supporting the Tarbell MDL-1011 floppy disk interface are available at:
https://deramp.com/downloads/altair/software/tarbell_floppy_controllers/single_density_controller/

16.1.3 TARBELL Controller Limitations

The TARBELL controller does not currently support the WD17XX Type II command multibyte record flag ('m' bit 4), block length flag ('b' bit 3), or data address mark flag ('a1a0' bits 1-0), the Read Track Type III command, or the Type IV command interrupt condition flags ('li' bits 3-0). This functionality will be added at a later date.

DMA is not currently supported by the TARBELL simulator.

17 JADE Double D Floppy Disk Controller Simulation

JADE Double D Floppy Disk Controller support was added by Patrick A. Linstruth, patrick@deltecent.com.

17.1 Overview

The JADE Double D Floppy Disk Controller simulator is capable of supporting single density and double density 8" media with 77 tracks and 128 byte sectors. Single and double density diskettes may be mixed on a drive-by-drive basis. Single density disks have 26 sectors per track. Double density have 50. The simulated controller includes a PROM bootstrap loader located at F000H. The PROM has been patched to utilize the MITS 88-2SIO. Using the simulated Jade Double D floppy disk controller, it is possible to load and run CP/M 2.2 as was provided by JADE Computer Products.

17.1.1 JADE Double D Controller Parameters

The JADED D controller supports several parameters which can be configured by the simulator:

IOBASE – Change I/O port address

MEMBASE – Change memory bank window base address

WRTPROT – Enable write protect

WRTENB – Enable writing to disks

PROM – Enable boot PROM at F000

NOPROM – Disable boot PROM

VERBOSE – Enable operational status messages

QUIET – Disable operational status messages

DEBUG – enable debug tracing, useful for debugging software. One or more debug levels may be selected at any given time. Several debug tracing levels are provided:

- ERROR – Error messages, these are bugs in the simulation or in the way a program running on the simulator accesses the controller. This message level is on by default.
- CMD – Disk controller commands.
- RDDATA – Read Data messaging
- WRDATA – Write Data messaging
- FORMAT – Format Track messaging
- VERBOSE – Extra verbosity for debugging.

NODEBUG – turn off one or more debug message levels.

The JADED D controller supports four drive units, labeled JADED D0 through JADED D3. If a drive is attached to a non-existent disk file, the disk file will be created.

17.1.2 JADED D Example Usage

```
sim> set jadedd ena           - enable JADE DD Controller
sim> attach jadedd0 jadedd-sd-sim-56k.dsk - attach 56K CP/M disk image
sim> boot jadedd0             - boot jade56k.dsk (or "g f000")
```

CP/M 2.2 disk images supporting the JADE Double D Disk Controller and 88-2SIO are available at: <https://github.com/deltecent/jadedd-cpm22>

17.1.3 JADE Double D Controller Limitations

The JADE Double D contains an on-board Z80A microprocessor with 2K of static memory. The on-board processor runs simultaneously with and transparent to the Altair's 8080 or Z80 processor and memory. The Double D's Z80A and on-board Disk Controller Module (DCM) software are only simulated. Although the simulator, like the actual hardware, loads the DCM from disk into memory bank 0 during the boot process (and can be examined/alterd by the host CPU), the DCM code does not execute within the simulator. Changes to the DCM in RAM or on disk will not change how the emulator operates. This is also true for the Boot Loader Transient (BLT) module and FORMAT.COM.

The JADE Double D simulator is specifically designed to run CP/M 2.2 as distributed by JADE Computer Products as described in the "CP/M 2.2 – Double D – Release 2" software manual. Other versions of CP/M or operating systems designed to operate with the JADE Double D will likely not work with this simulator.

When changing memory size, MOVCPM updates the BLT at track 0, sector 2, to match the new location of DDBIOS. Since the simulator emulates the BLT, the boot PROM built into the simulator determines this location by looking at the jump vector table at the beginning of DDBIOS (JMP INIT). If DDBIOS is modified such that INIT does not appear within the first 256 bytes of DDBIOS, this mechanism will not work, and CP/M will fail to load.

The JADE Double D Disk Controller emulator does not currently support double-sided drives.

The Serial Interface on the Double D is not supported.

18 Advanced Digital Corporation Super-Six Simulation

ADC Super-Six Single-Board Computer support was added by Howard M. Harte, hharte@hartetec.com.

18.1 Overview

The Advanced Digital Corporation Super-Six SBC is a Z80-based single board computer on an S-100 bus card. It has 128K of RAM, and a WD179x-based floppy disk controller.

Additional devices include:

ADCS6 – ADC Super-Six SBC.

18.1.1 ADCS6 SBC Parameters

The ADCS6 SBC supports several parameters which can be configured by the simulator:

ROM – Enable RDOS ROM at C000-DFFFh.

NOROM – Disable RDOS ROM.

DEBUG – enable debug tracing, useful for debugging software. One or more debug levels may be selected at any given time. Several debug tracing levels are provided:

- ERROR – Error messages, these are bugs in the simulation or in the way a program running on the simulator accesses the controller. This message level is on by default.
- SEEK – Seek messages, related to head positioning.
- CMD – Disk controller commands.
- RDDATA – Read Data messaging
- WRDATA – Write Data messaging
- STATUS – Status register reading
- VERBOSE – Extra verbosity for debugging.
- DRIVE – Messaging specific to drive, i.e.: Motor on/off, side selection.
- IRQ – Interrupt debugging
- DMA – Z80-DMA register debugging

NODEBUG – turn off one or more debug message levels.

18.1.2 ADCS6 SBC Configuration Registers

The CROMFDC controller has several configuration registers that can be examined and deposited by the simulator. The defaults are configured for a standard 20MB hard disk. These registers are:

J7 – Jumper block J7 setting, see ADC Manual for details.

The ADCS6 supports four drives, labeled ADCS60 through ADCS63. If a drive is attached to a non-existent image file, the image file will be created, and the user will be asked for a comment description of the disk. SIMH adds its own IMD header to the comment field, along with information about the version of the controller core (in this case WD179x) as well as the SIM_IMD module, to help facilitate debugging. The SIM_IMD module will automatically format the new disk image in IBM 3740 Single-Sided, Single-Density format. If the user wishes to use the disk in another format, then it should be reformatted using the FMT8.COM program under CP/M 2.2.

18.1.3 ADCS6 SBC Limitations

The ADCS6 simulation does not support the Z80-DMA, CTC, parallel ports, or interrupt-driven operation. The ADCS6 bank switching and ROM are not implemented fully.

19 N8VEM Single Board Computer Simulation

N8VEM Single Board Computer support was added by Howard M. Harte, hharte@hartetec.com.

19.1 Overview

The N8VEM Single Board Computer is a homebrew Z80 system designed by Andrew Lynch. This SBC can has 1MB of EPROM, 512KB of RAM, and can run CP/M 2.2. More details about the N8VEM are on the following newsgroup:

<http://groups.google.com/group/n8vem>

Additional devices include:

N8VEM – N8VEM Single-Board Computer.

19.1.1 N8VEM SBC Parameters

The N8VEM SBC supports several parameters which can be configured by the simulator:

DEBUG – enable debug tracing, useful for debugging software. One or more debug levels may be selected at any given time. Several debug tracing levels are provided:

- **ERROR** – Error messages. This message level is on by default.
- **PIO** – 8255 Parallel I/O port messages.
- **UART** – Serial port messages.
- **RTC** – Real-Time Clock messages.
- **ROM** – ROM messages.
- **VERBOSE** – Extra verbosity for debugging.

NODEBUG – turn off one or more debug message levels.

19.1.2 N8VEM SBC Configuration Registers

The N8VEM SBC has several configuration registers that can be examined and deposited by the simulator. These registers are:

SAVEROM – When set to 1, the ROM data will be saved to an attached file.

SAVERAM – When set to 1, the RAM data will be saved to an attached file.

PIO1A – 8255 PIO1A port.

PIO1B – 8255 PIO1A port

PIO1C – 8255 PIO1A port

PIOCTRL – 8255 PIO Control register

The N8VEM supports two storage devices: N8VEM0 and N8VEM1.

N8VEM0 saves data from the ROM to a raw binary file when SAVEROM is set to 1, and the unit is detached. Since the N8VEM has 1MB of ROM, the file created will be 1048576 bytes in length. This file can then be burned into an EPROM for use with the actual N8VEM hardware.

N8VEM1 saves data from the RAM to a raw binary file when SAVERAM is set to 1, and the unit is detached. Since the N8VEM has 512KB of RAM, the file created will be 524288 bytes in length. This file is useful as a “core dump” to examine the state of a running system. It can also serve to model persistent storage for the N8VEM RAM drive, in case an 512KB NVRAM is used in place of the 512KB SRAM on the N8VEM.

19.1.3 N8VEM SBC Limitations

The DS1302 Real-Time Clock on the N8VEM is not supported by the simulation. The 8255 PIO ports serve no real purpose, other than that the values written to them can be read by the simulator.

20 PMMI MM-103 MODEM and Communications Adapter

PMMI MM-103 support was added by Patrick A. Linstruth, patrick@deltecent.com.

20.1 Overview

The MM-103 is a MODEM from Potomac Micro-Magic, Inc. (PMMI). The term MODEM is a contraction of MOdulator-DEModulator. The MM-103 combines data transmission and telephone line handling functions in a single device. The MM-103 supports baud rates from 61 to 600 baud using FSK modulation.

This device simulates the MM-103 data communications portion but does not simulate the MODEM functionality. MODEM functionality must be simulated by attaching a host serial port or modem to the PMMI device using the “Attach” command.

20.1.1 PMMI Device Parameters

The PMMI device supports several parameters which can be configured by the simulator:

- **DEBUG** – enable debug tracing, useful for debugging software. One or more debug levels may be selected at any given time. Several debug tracing levels are provided:
 - **ERROR** – Error messages.
 - **STATUS** – Status change messages.
 - **VERBOSE** – Extra verbosity for debugging.
- **NODEBUG** – turn off one or more debug message levels.
- **IOBASE** – Change the I/O port address of the PMMI (default = C0H)
- **RTS** – RTS will follow DTR
- **NORTS** – RTS will not follow DTR
- **BAUD** – Set baud rate (default = 300)

20.1.2 PMMI Example Usage

The MM-103 was supported by various communications software for CP/M. This example will use NightOwl Software’s Modem Executive (MEX) which can be downloaded from GitHub using the link below.

Using a breakout box, connect the following pins on your host’s serial port:

```
RxD <-> TxD
DTR <-> CTS
```

The following example will use MEX under CP/M to simulate dialing a phone number and communicating with a remote system by looping back transmitted data to the receiver:

```
sim> dep CLOCK 2000 ; simulate 2MHz clock speed
sim> set SIO nosleep ; disable console sleeps
sim> set PMMI ena ; enable PMMI device
sim> attach PMMI connect=/dev/ttyUSB0 ; Attach host serial port
sim> attach dsk0 ; attach CP/M boot disk
sim> attach dsk1 MEXPMMI.DSK ; attach MEX disk
```

```
sim> load dbl.bin ff00 ; load Disk Boot Loader
sim> go ff00 ; boot the disk
```

```
56K CP/M
Version 2.2mits (07/28/80)
Copyright 1980 by Burcon Inc.
```

```
A>b:
B>mexpmmi
```

```
MEX (Modem Executive) V1.14
Clone Level 1
(for aid, type HELP or "?")
Copyright (C) 1984, 1985
by NightOwl Software, Inc.
```

```
*****
* PMMI overlay version - 2.2c *
* Base port = C0 hex. *
* No carrier present. *
*****
```

```
[MEX] B0>> call 5551212
Dialing: .disc. .off-h. 5551212: Try #1 .wait.
```

```
Connected @300 bps
```

```
[MEX] [Term: CTL-J + "?" for help]
```

```
Hello, world!
```

The following example will use MEX under CP/M to connect to a R/CPM system over telnet:

```
sim> dep CLOCK 2000 ; simulate 2MHz clock speed
sim> set SIO nosleep ; disable console sleeps
sim> set PMMI ena ; enable PMMI device
sim> attach pmmi connect=67.164.159.109:4667 ; Attach to IP:PORT
```

```
sim> attach dsk0 ; attach CP/M boot disk
sim> attach dsk1 MEXPMMI.DSK ; attach MEX disk
sim> load dbl.bin ff00 ; load Disk Boot Loader
sim> go ff00 ; boot the disk
```

```
56K CP/M
Version 2.2mits (07/28/80)
Copyright 1980 by Burcon Inc.
```

```
A>b:
B>mexpmmi
```

```
MEX (Modem Executive) V1.14
Clone Level 1
(for aid, type HELP or "?")
Copyright (C) 1984, 1985
by NightOwl Software, Inc.
```

```
*****
* PMMI overlay version - 2.2c *
* Base port = C0 hex. *
* No carrier present. *
*****
```

```
[MEX] B0>>set online
.on-line.
[MEX] B0>>t
```

```
[MEX] [Term: CTL-J + "?" for help]
```

```
HOW MANY NULLS (0-9) DO YOU NEED? 0
```

```
Welcome to the virtualaltair.com Remote CP/M System!
```

The disk images used in the above examples may be downloaded from:
<https://github.com/deltecent/pmmi-cpm22>

20.1.3 PMMI and SIMH Timing

The PMMI device and communications software for CP/M depend on predicable timing to function properly. This is accomplished by setting CPU's "CLOCK" register and using the M2SIO0 device for console input and output. If using the SIO device for console input and output, use "SET SIO NOSLEEP" to disable sleeps during keyboard checks as this interferes with SIMH's timing.

21 Hayes Micromodem 100

Hayes Micromodem 100 support was added by Patrick A. Linstruth, patrick@deltecent.com.

21.1 Overview

Hayes made two S-100 MODEM adapters, the 80-103A and Micromodem 100. With the exception of a 50ms hardware timer available on the Micromodem 100, both modems are software compatible.

This device simulates the Micromodem 100 data communications portion but does not simulate the MODEM (MOdulator / DEModulator) functionality. MODEM functionality must be simulated by attaching a host serial port or modem to the HAYES device using the “Attach” command.

The Micromodem 100 does not support DTR, RTS, DSR, or CTS modem signals. To accommodate using the HAYES device with serial ports and sockets, the device will always raise RTS and will raise DTR when RI goes high or when the modem goes “off hook” in originate mode. The device will lower DTR when the modem goes “on hook” or DCD goes low.

21.1.1 HAYES Device Parameters

The HAYES device supports several parameters which can be configured by the simulator:

- **DEBUG** – enable debug tracing, useful for debugging software. One or more debug levels may be selected at any given time. Several debug tracing levels are provided:
 - **ERROR** – Error messages.
 - **STATUS** – Status change messages.
 - **VERBOSE** – Extra verbosity for debugging.
 - **DEBUG** – Debug messages.
- **NODEBUG** – turn off one or more debug message levels.
- **IOBASE** – Change the I/O port address of the HAYES (default = 80H)

21.1.2 HAYES Example Usage

The Hayes Micromodem 100 is supported by various communications software for CP/M. This example will use the MM100 utility that was provided by Hayes. The software used in this example can be downloaded from GitHub using the link below.

Using a breakout box, connect the following pins on your host’s serial port:

```
RxD <-> TxD
DTR <-> DCD
RTS <-> RI
```

The following example will use MM100 under CP/M 2.2 to simulate dialing a phone number and communicating with a remote system by looping back transmitted data to the receiver. RTS will be used to drive RI and DTR will drive DCD:

```
sim> dep CLOCK 2000 ; simulate 2MHz clock speed
sim> set SIO nosleep ; disable console sleeps
sim> set HAYES ena ; enable HAYES device
sim> attach HAYES connect=/dev/ttyUSB0 ; Attach host serial port
```

```
sim> attach dsk0 ; attach CP/M boot disk
sim> attach dsk1 MM100.DSK ; attach MM100 disk
sim> load DBL.BIN ff00 ; load Disk Boot Loader
sim> go ff00 ; boot the disk
```

56K CP/M
Version 2.2mits (07/28/80)
Copyright 1980 by Burcon Inc.

```
A>b:
B>mm100
```

```
Hayes Microcomputer Products, Inc.
Micromodem 100 Terminal program ver. 1.2
8 DATA BITS
1 STOP BITS
NO PARITY
300 BAUD
FULL DUPLEX
CAPTURE BUFFER CLEARED
DEBUG MODE OFF
```

```
COMMAND:D 555-1212
DIALING-555-1212
WAITING FOR CARRIER, PRESS ANY KEY TO ABORT.
CONNECTION ESTABLISHED
Hello, world!
```

```
[^A]
COMMAND:G
[ HUNG UP ]
```

```
[* LOST CARRIER *]
[ HUNG UP ]
```

```
COMMAND:X
```

The disk images used in the above examples may be downloaded from:

<https://github.com/deltecent/hayes-mm100>

21.1.3 HAYES and SIMH Timing

The HAYES device and communications software for CP/M depend on predicable timing to function properly. This is accomplished by setting the CPU's "CLOCK" register and using the M2SIO0 device for console input and output. If using the SIO device for console input and output, use "SET SIO NOSLEEP" to disable sleeps during keyboard checks that interfere with SIMH's timing. Software that uses the 50ms hardware timer on the Micromodem 100 should be able run at any CPU clock speed.

22 ImageDisk (IMD) Disk Image Support in SIMH

ImageDisk (IMD) disk image file support for SIMH was added by Howard M. Harte, hharte@hartetec.com.

22.1 Overview

The ImageDisk (IMD) file format is a portable format which includes all metadata required to accurately describe a soft-sectored floppy disk. The IMD file format was developed by Dave Dunfield, along with a set of ImageDisk utilities for creating ImageDisk disks from raw binary files and from real floppy disks. In addition, IMD disk images can be written back to real floppies for use on actual hardware. SIMH support for ImageDisk is provided by the SIM_IMD module written by Howard M. Harte. The SIM_IMD module provides functions for creating, opening, reading, writing, formatting, and closing IMD files. The i8272 and WD179x floppy controller core simulations leverage the SIM_IMD module for low-level disk access.

22.2 References

More information and support for ImageDisk, including a detailed description of the IMD file format, and utilities for creating and manipulating IMD files can be found on Dave Dunfield's website.

23 CP/M-68K Simulation

Based on work by David W. Schultz (<http://home.earthlink.net/~david.schultz>) you can run Digital Research CP/M-68K as follows. Unpack cpm68k.zip and issue the command altairz80 cpm68k or the following commands at the simh prompt:

```
sim> set cpu m68k
sim> attach hdisk2 diskc.cpm.fs
sim> boot hdisk2
```

```
CP/M-68K(tm) Version 1.2 03/20/84
Copyright (c) 1984 Digital Research, Inc.
```

```
CP/M-68K BIOS Version 1.0
Simulated system of April 2014
TPA =16251 K
```

```
C>AUTOST.SUB
AUTOST.SUB?
C>
```

Typing "bbye" at the "C>" command prompt brings you back to SIMH.